



*Integrated Network Interface Card*

*User's Manual*

*TallyGenicom® 6600 Series Printers*



## READ THIS SOFTWARE LICENSE AGREEMENT BEFORE USING THIS PRINTER

### Software License Agreement

CAREFULLY READ THE FOLLOWING TERMS AND CONDITIONS BEFORE USING THIS PRINTER. USING THIS PRINTER INDICATES YOUR ACCEPTANCE OF THESE TERMS AND CONDITIONS. IF YOU DO NOT AGREE TO THESE TERMS AND CONDITIONS, PROMPTLY RETURN THE PRINTER AND ALL ACCOMPANYING HARDWARE AND WRITTEN MATERIALS TO THE PLACE YOU OBTAINED THEM, AND YOUR MONEY WILL BE REFUNDED.

### Definitions

"Software" shall mean the digitally encoded, machine-readable data and program. The term "Software Product" includes the Software resident in the printer and its documentation. The Software Product is licensed (not sold) to you, and TallyGenicom either owns or licenses from other vendors who own, all copyright, trade secret, patent and other proprietary rights in the Software Product.

### License

1. Authorized Use. You agree to accept a non-exclusive license to use the Software resident in the printer solely for your own customary business or personal purposes.
2. Restrictions.
  - a. To protect the proprietary rights of TallyGenicom, you agree to maintain the Software Product and other proprietary information concerning the typefaces in strict confidence.
  - b. You agree not to duplicate or copy the Software Product.
  - c. You shall not sublicense, sell, lease, or otherwise transfer all or any portion of the Software Product separate from the printer, without the prior written consent of TallyGenicom.
  - d. You may not modify or prepare derivative works of the Software Product.
  - e. You may not transmit the Software Product over a network, by telephone, or electronically using any means; or reverse engineer, decompile or disassemble the Software.
  - f. You agree to keep confidential and use your best efforts to prevent and protect the contents of the Software Product from unauthorized disclosure or use.
3. Transfer. You may transfer the Software Product with the printer, but only if the recipient agrees to accept the terms and conditions of this Agreement. Your license is automatically terminated if you transfer the Software Product and printer.

### Limited Software Product Warranty

TallyGenicom warrants that for ninety (90) days after delivery, the Software will perform in accordance with specifications published by TallyGenicom. TallyGenicom does not warrant that the Software is free from all bugs, errors and omissions.

### Remedy

Your exclusive remedy and the sole liability of TallyGenicom in connection with the Software is replacement of defective software with a copy of the same version and revision level.

### Disclaimer of Warranties and Limitation of Remedies

1. THE PARTIES AGREE THAT ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE AND MERCHANTABILITY ARE EXCLUDED.  
TallyGenicom does not warrant that the functions contained in the Software will meet your requirements or that the operation of the Software will be uninterrupted or error free. TallyGenicom reserves the right to make changes and/or improvements in the Software without notice at any time.
2. IN NO EVENT WILL TALLYGENICOM BE LIABLE FOR LOST PROFITS, LOST DATA, BUSINESS INTERRUPTIONS, OR ANY OTHER DIRECT, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OF OR INABILITY TO USE THIS PRODUCT, EVEN IF HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, OR ANY DAMAGES CAUSED BY THE ABUSE OR MANIPULATION OF THE SOFTWARE. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.
3. TallyGenicom will not be liable for any loss or damage caused by delay in furnishing a Software Product or any other performance under this Agreement.
4. Our entire liability and your exclusive remedies for our liability of any kind (including liability for negligence except liability for personal injury caused solely by our negligence) for the Software Product covered by this Agreement and all other performance or nonperformance by us under or related to this Agreement are limited to the remedies specified by this Agreement.
5. California law governs this Agreement.

### Termination of License Agreement


This License shall continue until terminated. This license may be terminated by agreement between you and TallyGenicom or by TallyGenicom if you fail to comply with the terms of this License and such failure is not corrected within thirty (30) days after notice. When this License is terminated, you shall return to the place you obtained them, the printer and all copies of the Software and documentation.

### U.S. Government Restricted Rights

Use, duplication or disclosure by the Government is subject to restrictions as set forth in the Rights in Technical Data and Computer Software clause at FAR 242.227-7013, subdivision (b) (3) (ii) or subparagraph (c) (1) (ii), as appropriate. Further use, duplication or disclosure is subject to restrictions applicable to restricted rights software as set forth in FAR 52.227-19 (c) (2).

### Acknowledgement of Terms and Conditions

YOU ACKNOWLEDGE THAT YOU HAVE READ THIS AGREEMENT, UNDERSTAND IT, AND AGREE TO BE BOUND BY ITS TERMS AND CONDITIONS. NEITHER PARTY SHALL BE BOUND BY ANY STATEMENT OR REPRESENTATION NOT CONTAINED IN THIS AGREEMENT. NO CHANGE IN THIS AGREEMENT IS EFFECTIVE UNLESS WRITTEN AND SIGNED BY PROPERLY AUTHORIZED REPRESENTATIVES OF EACH PARTY. BY USING THIS PRINTER, YOU AGREE TO ACCEPT THE TERMS AND CONDITIONS OF THIS AGREEMENT.



---

## Table of Contents

<b>1</b>	<b>Introduction .....</b>	<b>13</b>
	Overview .....	13
	What Is The NIC?.....	13
	What Special Features Are Available?.....	13
	Logical Printer Architecture .....	15
	Destinations/Queues.....	17
	Models.....	17
	Speed Setting for 10/100Base-T.....	18
	Conventions Used In This Manual .....	20
	Notes And Notices.....	20
<b>2</b>	<b>Installation And Configuration .....</b>	<b>21</b>
	Installation .....	21
	Connecting To The Network .....	21
	Configuration Tools .....	21
	Printing A NIC Test Page .....	22
	Configuration Using The Control Panel.....	23
	NIC Verification .....	24
	IP Address Configuration Using The Control Panel .....	25
	HTML Forms .....	26
	Telnet .....	27
	Remote Shell.....	27
	Setup Through Data Stream .....	28

## Table of Contents

---

<b>3</b>	<b>NIC Web Server .....</b>	<b>29</b>
	Overview .....	29
	NIC Configuration.....	30
	Network Configuration.....	32
	TCP/IP Network .....	32
	Print Path Configuration .....	35
	Destination Settings .....	35
	Current Model Settings .....	37
	Print Model Configuration.....	40
	Log Path Configuration .....	43
	SNMP Configuration .....	45
	Administration Configuration .....	49
	System Information .....	50
	Passwords .....	52
	System Configuration.....	53
	Status .....	53
	Status - I/O Port .....	54
	Status - Network.....	54
	Help.....	54
<b>4</b>	<b>Windows Configuration .....</b>	<b>55</b>
	Overview .....	55
	Windows Environment Description .....	55
	Windows NIC Configuration .....	56
	Mandatory .....	56
	Optional.....	56
	Configuration Using ARP .....	56
	Communicating Across Routers.....	58
	Changing Workgroup Names.....	59
	Changing Destination Names .....	60
	Windows Host Configuration .....	62
	Printer Driver Setup Wizard .....	62
	Windows Driver Usage Information.....	65

## Table of Contents

---

<b>5</b>	<b>Unix Configuration.....</b>	<b>67</b>
	Overview .....	67
	Unix Environment Description .....	67
	Unix NIC Configuration.....	68
	Mandatory .....	68
	Optional.....	68
	Using ARP.....	68
	Using RARP .....	70
	Using BOOTP .....	71
	Communicating Across Routers.....	72
	Unix Host Configuration .....	73
	Manual System V Host Setup .....	73
	NIC Installation on HP-UX.....	74
	Solaris 2.6 – 7 NIC Setup.....	75
	Manual LPR/LPD Host Setup.....	76
	Printing With FTP .....	78
	Direct Socket Printing.....	79
<b>6</b>	<b>AS/400 Configuration, ASCII Printer .....</b>	<b>81</b>
	Overview .....	81
	Configuring AS/400 For ASCII Using TCP/IP.....	83
	Configuring With ADDTCPIFC .....	83
	Configuring A Router Definition With ADDTCP RTE .....	85
	Configuring A Local Domain And Hostname.....	85
	Configuring A TCP/IP Host Table Entry .....	85
	Configuring The AS/400 For Printing .....	86
	Setting Up Printing For ASCII Files.....	86
	Verify Printing On AS/400 .....	92
	AS/400 ASCII Troubleshooting .....	93

## Table of Contents

---

<b>7</b>	<b>Monitoring Printers .....</b>	<b>95</b>
	Implementing Printer Management .....	95
	Agent/Manager Model.....	95
	MIB.....	96
	SNMP.....	97
	Monitoring Tools.....	97
	Monitoring With AIX NetView/6000 .....	97
	PrintNet Enterprise Suite.....	98
	Setting The SNMP Community Name.....	98
<b>8</b>	<b>Commands .....</b>	<b>99</b>
	Command Shell Overview.....	99
	npsh Access Methods.....	99
	Main npsh Command Prefixes .....	100
	Getting Command Help.....	100
	Complete Command List.....	101
	Store Commands .....	101
	Set Commands .....	109
	List Commands .....	122
	Miscellaneous Commands .....	124
<b>9</b>	<b>Extra Features .....</b>	<b>129</b>
	NIC Security .....	129
	Users And Passwords.....	129
	Reset The NIC Password.....	131
	TCP Access Lists .....	131
	Printer Monitoring And Logging.....	133
	Printer And Print Job Monitoring .....	133
	Printer Logging Through Logpaths .....	134
	Downloading Software Through The Network Interface Card (NIC).....	135
	NIC Naming Schemes.....	137
	Periodic Ping .....	137

## Table of Contents

---

<b>A</b>	<b>Troubleshooting Tips .....</b>	<b>139</b>
	Windows Troubleshooting Tips .....	139
	Technical Support .....	139
	NIC Cannot Be Found On The Network.....	140
	HTML Configuration Forms Will Not Display.....	140
	Errors Occur When Defining An LPR Printer .....	141
	Cannot Browse The NIC On The Network.....	141
	Printer Errors When Printing Or No Output.....	142
	TCP/IP Access Problem.....	142
	Web Browser/HTTP Problem.....	143
	Windows NT 4.0 Or 2000 Host Setup Problems.....	144
	Unix Troubleshooting Tips.....	146
	NIC Cannot Be Found On The Network.....	146
	Nothing Prints.....	147
	Stair-Stepped Output .....	148
	No Form Feed Or Extra Page Comes Out.....	149
	Front Panel Message – Dynamically Set Params Read Only .....	149
<b>B</b>	<b>Customer Support .....</b>	<b>151</b>
	TallyGenicom Customer Support Center .....	151
	TallyGenicom Supplies Department.....	152
	Corporate Offices .....	152
<b>C</b>	<b>Glossary .....</b>	<b>155</b>



---

## Table of Contents



*Integrated Network Interface Card  
User's Manual  
TallyGenicom<sup>®</sup> 6600 Series Printers*



This document contains proprietary information protected by copyright. No part of this document may be reproduced, copied, translated or incorporated in any other material in any form or by any means, whether manual, graphic, electronic, mechanical or otherwise, without the prior written consent of TallyGenicom®.

TallyGenicom makes no representations or warranties of any kind regarding this material, including, but not limited to, implied warranties of merchantability and fitness for a particular purpose. TallyGenicom shall not be held responsible for errors contained herein or any omissions from this material or for any damages, whether direct or indirect, incidental or consequential, in connection with the furnishing, distribution, performance, or use of this material. The information in this manual is subject to change without notice.

COPYRIGHT 2010, 2012 PRINTRONIX, INC.

## Trademark Acknowledgements

---

Portions of this manual used by permission of Wyndham Technologies, Inc. Copyright 1991-1999 Wyndham Technologies Inc.

AIX, AS/400, NetView, and OS/2 are registered trademarks, and AFP, Intelligent Printer Data Stream, IPDS, Print Services Facility, and PSF are trademarks of International Business Machines Corporation.

Code V is a trademark of Quality Micro Systems, Inc.

DG/UX is a registered trademark of Data General Corporation.

Frontier Technologies and SuperTCP are trademarks or registered trademarks of Frontier Technologies Corporation.

FTP Software and OnNet are trademarks or registered trademarks of FTP Software, Inc.

HP-UX is a registered trademark of Hewlett-Packard Company.

IGP, LinePrinter Plus, PGL, Network Interface Card, PrintNet and Printronix are registered trademarks of Printronix, Inc.

IRIX is a registered trademark of Silicon Graphics, Inc.

LINUX is a registered trademark of Linus Torvalds.

Microsoft, MS-DOS, Windows, Windows 95, Windows 98, Windows Me, Windows NT and Windows 2000 are registered trademarks of Microsoft Corporation.

NetManage and Chameleon are trademarks or registered trademarks of NetManage, Inc.

Netscape, Netscape Navigator, and the Netscape Communications logo are trademarks of Netscape Communications Corporation.

Novell and NetWare are registered trademarks of Novell, Inc.

PostScript is a registered trademark of Adobe Systems Inc.

Solaris is a registered trademark of Sun Microsystems, Inc.

TallyGenicom brand is owned by Printronix, Inc.

Ultrix is a registered trademark of Digital Equipment Corporation.

Unix is a registered trademark of X/Open Company Limited.



---

# 1

## *Introduction*

### Overview

---

This chapter introduces you to the Network Interface Card (NIC) architecture and special features, as well as providing information on installation and configuration tools.

#### **What Is The NIC?**

---

The NIC allows you to attach printers on a local area network (LAN) rather than attaching them directly to a host system. Following simple configuration steps, these peripherals can be simultaneously shared with users on the network whether you are using TCP/IP or NetBIOS over TCP/IP.

#### **What Special Features Are Available?**

---

The NIC offers an extensive list of features including:

- built-in HTML forms for easy cross-platform configuration
- availability of PrintNet<sup>®</sup> Enterprise, a remote management software utility
- a detailed and easy-to-use command shell built-in to the firmware
- multi-level configuration security through passwords, permission levels, and access lists
- WAN-wide communication access

## Chapter 1 Overview

---

- numerous printer logging methods (e.g., automatic email) to record printer errors and usage
- remote management through HTML forms, Telnet sessions, `rsh/rcmd/remsh` commands, SNMP, and pre-defined log methods
- extensive built-in troubleshooting tools
- built-in `telnet` and `ping` clients
- configurable memory usage by disabling protocols and destination services
- multiple destinations/queues for versatile printer manipulation and distinct print setups
- header and trailer strings to instruct printers on font, pitch, printing, etc.
- flexible naming conventions
- automatic network connection and frame type sensing
- simultaneous printing across all I/O ports and all supported protocols
- multiple network protocol support

---

## Logical Printer Architecture

---

The NIC implements a logical printer architecture which gives the system administrator the possibility to configure the print server to handle and act upon the print data in several ways. When a print job comes through the print server, there is a certain logical print path that it follows before it gets to the printer. Each logical print path consists of a sequence of logical steps where extra processing may be performed on the print data before it is sent to the printer. This ability to preprocess the print data before it is sent to the printer allows elimination of certain printing problems, or implementation of printer enhancements that may be difficult and time consuming to solve or introduce at the system, spool or queue level. The preprocess ability is also simplistic to perform at the print server level.

The logical print path for a print job going through NIC consists of three different phases:

- **Phase 1** - the host sends the job to a destination or queue on NIC (e.g. d1prn).
- **Phase 2** - the print job passes through the associated “model” (e.g. model “m1”) on NIC for any extra processing associated with the model.
- **Phase 3** - the processed print job is directed to the printer for output.

## Chapter 1 Logical Printer Architecture




Figure 1. Print Path

---

## Destinations/Queues

For every I/O port on NIC, there is at least one pre-defined logical print queue or destination to accept print jobs destined for it. This includes print jobs that are sent directly to the I/O port, such as port 9100. These queue or destination names are pre-defined but can be changed by the user.

---

## Models

For every destination or queue, there is a pre-defined model associated with it. The model defines how the print job will be processed as it passes through to the printer. Models are a set of mini filters that can be used to modify the print data stream. The functions available for each model are as follows:

1. Insert carriage return after line feed
2. Insert a banner page before or after each print job
3. Insert header strings to
  - Print using upper tray's paper
  - Printer using lower tray's paper
  - Print in landscape mode
  - Print in portrait mode
4. Insert trailer strings to
  - Reset the printer once the print job completes
  - Force the end of the job
  - Perform a form feed at the end of the data

## Chapter 1 Logical Printer Architecture

---

5. Log one or all of the following information as each print job passes through the model
  - Job ID and username
  - User ID and three messages per job about the start and finish
  - Checksum value of the data transferred
  - Miscellaneous messages from the printer
  - Status of the printer based on the port interface signals
6. Load a specific printer configuration before processing a print job
  - Specify a printer configuration to be associated with a print queue.
  - When a job is set to that print queue, the associated printer configuration will be loaded before the job is processed.
  - Feature allows you to define up to eight unique and independent printer personalities in a single printer.
  - Allows you to effectively have eight different printers in one.

### Speed Setting for 10/100Base-T

---

When the router is set to auto-negotiation enable, the following is the correct behavior of the NIC with each setting:

#### 1. **10mbps Half Duplex**

Use parallel detection because the NIC is using force mode and thus has auto-negotiation disabled.

PORs to 10mbps Half Duplex. Resets to 10mbps Half Duplex. Reconnection at switch maintains 10mbps Half Duplex.

#### 2. **10mbps Full Duplex**

Use parallel detection because the NIC is using force mode and thus has auto-negotiation disabled.

PORs to 10mbps Full Duplex. Resets to 10mbps Full Duplex. Reconnection at switch maintains 10mbps Full Duplex.

---

## Speed Setting for 10/100Base-T

### 3. 100mbps Half Duplex

Use parallel detection because the NIC is using force mode and thus has auto-negotiation disabled.

PORs to 100mbps Half Duplex. Resets to 100mbps Half Duplex. Reconnection at switch results in 100mbps Half Duplex.

### 4. 100mbps Full Duplex

Use parallel detection because the NIC is using force mode and thus has auto-negotiation disabled.

PORs to 100mbps Full Duplex. Resets to 100mbps Full Duplex. Reconnection at switch results in 100mbps Full Duplex.

### 5. NIC in Auto mode in 100mbps Full Duplex environment

Use auto negotiation to the highest common local and remote capability, i.e. 100 mbps Full Duplex in this case.

PORs to 100 mbps Full Duplex. Resets to 100 mbps Full Duplex. Reconnection at switch remains 100 mbps Full Duplex.

### 6. NIC in Auto mode in 10mbps Half Duplex environment (determined using 10 mbps Half Duplex hub)

Use auto-negotiation to the highest common local and remote capability, i.e. 10 mbps Half Duplex in this case.

PORs to 10 mbps Half Duplex. Resets to 10 mbps Half Duplex. Reconnection at switch maintains 10 mbps Half Duplex.

**NOTE:** With parallel detection, only speed can be determined. The duplex mode sets to half duplex.

## Chapter 1 Conventions Used In This Manual

---

### Conventions Used In This Manual

---

All uppercase print indicates control panel keys.

**Example:** Press the CLEAR key, then press the ONLINE key.

Quotation marks (“ ”) indicate messages on the Liquid Crystal Display (LCD).

**Example:** Press the ONLINE key. “OFFLINE” appears on the LCD.

Command syntax and examples are formatted as follows:

- The Courier font in **boldface** indicates commands that you type. For example:

At the prompt, type:

```
ping ftp.CompanyWebsite.com
```

- Regular Courier font indicates references to command syntax and output. For example:

The ftp.CompanyWebsite.com site is working properly.

- Variable values are shown in *italics* in command syntax, output, and in text. For example:

```
ping ipname
```

The *ipname* is working properly.

### Notes And Notices

---

For your safety and to protect valuable equipment, read and comply with the notes included in this manual. A description follows:

**NOTE:** A Note gives you helpful information and tips about printer operation and maintenance.

---

# 2

## *Installation And Configuration*

### Installation

---

The NIC provides an RJ-45 connector for 10/100Base-T (UTP) networks.

#### Connecting To The Network

---

To attach the NIC to a network, plug the network cable into the NIC connector.

### Configuration Tools

---

There are two parts to a NIC setup:

- Configuring the NIC so it can be seen on the network. This involves network-related settings (e.g., an IP address within TCP/IP environments) configured through the built-in command shell, npsh, or from the control panel.
- Configuring a host with a new printer so it knows how to send data to the NIC. Just being able to see the printer on the network does not mean you can automatically print to it. A host has to be told where to send the data.

**NOTE:** Some network environments do not require any network settings to be configured on the NIC. However, all network setups require configuration on the host end.

## Chapter 2 Configuration Tools

---

The following methods are available for configuring the NIC:

- via the control panel (wired and wireless)
- HTML forms
- Telnet
- Remote Shell
- PTX\_SETUP

### Printing A NIC Test Page

---

Always print an E-NET test page before performing any updates or network configuration using the following steps:

- For 6600 printers:
  - a. Take the printer offline. When the printer LCD reads “OFFLINE /Quick Setup”.
  - b. Press the left arrow until “Test Menu” appears.
  - c. Press the down arrow until “Pattern” appears.
  - d. Press the down arrow until “Printer Tests” appears.
  - e. Press the down arrow until “Shift Recycle” appears.
  - f. Press the left arrow until “Ethernet Test” appears.
  - g. Press Enter to print the test page. If the ENTER key is locked, press the up and down arrow keys simultaneously to unlock the control panel.

---

## Configuration Using The Control Panel

---

### Configuration Using The Control Panel

---

You can set NIC settings from the printer control panel.

**CAUTION** When the printer is first powered on, E-NET INIT. displays on the control panel. To prevent a loss of NIC configuration information, do not change the NIC settings while this message displays. When the initialization is complete, E-NET READY displays and now you can safely change the NIC settings from the control panel.

1. After the printer displays “E-NET READY,” take the printer offline.
2. Scroll through menu selections until “TCP/IP Menu” displays, then use the down arrow key to navigate to “ETHERNET ADDRESS”.
3. From the control panel, navigate to the IP Address, Subnet Mask, and Gateway Address menu options and enter the appropriate values. You must press the ENTER key after inputting each segment of the IP Address, Subnet Mask, and Gateway Address.
4. Place the printer online to start the NIC IP Address, Subnet Mask, and Gateway Address update process. This process will reboot the printer and may take several minutes. Wait until E-NET READY displays on the control panel.

**NOTE:** If you do not put the printer online, the settings you just entered will not take effect. Do not turn the printer off until E-NET READY displays. If you turn the printer off before the new values are written to memory in the NIC adapter, you will need to repower the printer and repeat step 3 and step 4.

**NOTE:** When the printer is moved from one network to another, the host may not be able to find the printer. Verify the IP address, Gateway Address, and Subnet Mask to make sure the settings are correct and routable.

Your NIC is now configured and connected to your network.

## NIC Verification

---

Before performing the verification, you must connect the NIC card to the network.

1. Print an E-NET test page (see steps on page 22) to verify the settings you made.
2. Verify the Netmask is correct in two locations on the E-NET test page:
  - NETWORK INTERFACES
  - TCP/IP ROUTING TABLE

The Netmask must be the same in both locations. For example, if the Netmask is listed as 255.255.255.0 in NETWORK INTERFACES and is listed as 255.255.255.255 in the TCP/IP ROUTING TABLE, they do not match and you must correct it for the Gateway.

Also, if a Gateway Address was entered, verify that “xxx.xxx.xxx.xxx is alive” is printed under the Default Gateway Ping Test, where xxx.xxx.xxx.xxx is the Gateway Address. If a Gateway Address was not entered, the Default Gateway Ping test is not required and will not display on the page.

If the Netmask does not match, complete the following steps:

- a. Take the printer offline.
- b. Using the control panel, modify the Gateway value to 0.0.0.0. (non-configured).
- c. Place the printer online and wait until E-NET IS READY displays.
- d. Take the printer offline and enter the Gateway Address you desire.
- e. Place the printer online and wait until E-NET IS READY displays. This saves the new Gateway Address.

Your NIC is now configured and connected to your network.

## IP Address Configuration Using The Control Panel

---

### IP Address Configuration Using The Control Panel

---

You can set the IP and other parameters from the front panel. Refer to the TCP/IP Menu in the User's Manual for more information.

#### CAUTION

**When the printer is first powered on, the message “E-NET INIT” displays on the control panel. To prevent a loss of NIC configuration information, do not change the NIC settings while this message displays. When the initialization is complete, “E-NET READY” displays, and you can safely change the NIC settings from the control panel.**

You need to set the IP addresses according to the TCP/IP environment that the printer is connected to. There are four parameters accessed from the printer control panel that are IP address related. These parameters are located in the "Ethernet Address" menu.

- **IP Address**

This is the host for IP addresses that have four segments. They display in four three-digit numbers separated by “.” which can be set to any value in the range of 0 to 255. Use the down and left arrow keys to navigate to the segment number.

- **Subnet Mask**

This is the subnet mask for the host IP that has four segments. They display in four three-digit numbers separated by “.” which can be set to any value in the range of 0 to 255. Use the down and left arrow keys to navigate to the segment number.

- **Gateway Address**

This is the gateway IP addresses that have four segments. They display in four three-digit numbers separated by “.” which can be set to any value in the range of 0 to 255. Use the down and left arrow keys to navigate to the segment number.

## Chapter 2 Configuration Tools

---

- **DHCP**

The DHCP option allows you to obtain host server IP addresses when powering onto the network. The DHCP can be configured to:

- Enable – each time you power on, the host server automatically assigns you a different address (if the IP address has not been previously assigned).
- Disable – You choose the host server IP address. After the selection, the IP Address remains fixed even after you reboot.

### HTML Forms

---

The NIC settings can be configured over TCP/IP through a standard Web browser. The NIC Web pages provide a way to access some of the commands built into the print server.

**NOTE:** If a router is used, make sure a Gateway value is configured.

To access the NIC home page:

1. Make sure the print server has an IP address and Subnet Mask so it is recognizable on your TCP/IP network.
2. Make sure your network station can successfully ping the NIC over the network.
3. Direct your Web browser to the URL:  
**http://IPaddress**  
(e.g., `http://192.75.11.9`)  
where **IPaddress** is the IP address of your NIC.

---

## Telnet

A TCP/IP command that helps configure NIC settings remotely. A TCP/IP host starts a Telnet session with the print server and logs into the device command shell to alter and view settings.

Example:

```
telnet 192.75.11.9
```

**NOTE:** The default User ID is root. There is no password by default, just press **ENTER**. If you have changed the default User ID and password, use the current User ID and the associated password instead of the defaults. For more information on setting passwords, see “NIC Security” on page 129.

---

## Remote Shell

A TCP/IP command that helps configure print server settings remotely. A TCP/IP host uses this command to remotely execute a single command on the NIC.

Example:

```
rsh spike list prn
```

This command remotely executes the npsd command `list prn` on the NIC named `spike`.

## Setup Through Data Stream

---

The PTX\_SETUP command can also be used to configure NIC settings through a printer data port (serial, parallel, etc.). This is done by creating a text file containing the PTX\_SETUP command and NIC internal command shell (npsh) commands. The text file is then sent to the printer through a data port to perform the NIC configuration. The following is an example of a PTX\_SETUP file that can be used to configure the NIC:

```
!PTX_SETUP
NIC_SETUP
store net 1 addr 190.168.2.11
END_NIC_SETUP
PTX_END
```

---

# 3

## *NIC Web Server*

### Overview

---

The NIC comes with a printer management tool that allows you to monitor, configure, and manage both the printer and its print job. The NIC comes with a web server that allows System Administrators and users access to its printer management capabilities from a standard web browser.

The NIC printer's IP address is used as a URL, similar to the URL of an Internet web page. When a web browser is activated and the printer's IP address is entered, the printer's embedded web server displays its home page, with links to the printer's and NIC's status and configuration settings.

You can configure the printer and check the printer status through the Web page. When an option is changed on the Web page, the change is reflected in the printer after the Send box is clicked. Click "Save Configuration on Printer Actions Page" to save the changes permanently.

Printer configuration parameters can be changed using the "Printer Configuration" link (refer to the *TG 6600 User's Manual* for details) and various printer actions can be made using the "Printer Actions" link.

## Chapter 3 NIC Configuration

---

All of NIC's configuration settings are protected by a password so unauthorized users cannot make changes. When you try to open any of the NIC 's configuration pages, you are asked for your user name and password. At the prompt, you need to enter `root` (unless you have another user configured with root privileges) followed by the associated password. If there is no password, press **ENTER**. For more information on setting passwords, refer to “NIC Security” on page 129.

After you configure the NIC settings, and click the SUBMIT button on the related form, re-power the NIC to ensure the latest settings are in use. To reset the NIC, go to the System form under the Configuration Menu and click the REBOOT button.

The embedded NIC Web server gives you the ability to configure the network settings, monitor printer status, and to manage print jobs.

### NIC Configuration

---

The Advanced Configuration menu items allow you to configure the settings for the following items:

- Network - this menu item allows you to change the network setting for each protocol: TCP/IP, and NetBIOS over TCP/IP.
- Print Path - this menu item allows you to change the name of the destination queues, and define how the print job will be preprocessed before printing. It allows you to select what information to log, and to specify the SMTP server's IP address.
- Print Model - this menu item allows you to specify the printer name and model. It also allows you to select banner page types, filters, header and trailer strings, and printer configurations.
- Log Path - this menu item allows you to specify the logpath name, type, and port.

- 
- **SNMP** - this menu item allows you to configure the SNMP trap manager settings. It also allows you to define the printer event types to monitor, and the e-mail address that should receive alert notifications.
  - **Administration** - this menu item allows you to define or change the printer name, location, description, etc.. It also allows you to change the root and guest user passwords.
  - **System** - this menu item allows you to reboot the NIC, or restore its settings to the factory default.

## Chapter 3 Network Configuration

### Network Configuration

The network configuration allows you to specify the setting for each network protocol. Beside each protocol name is a checkbox which allows you to enable or disable each protocol depending on your network printing needs.

**NOTE:** TCP/IP is the only supported protocol which is always enabled.

#### TCP/IP Network

TCP/IP

---


Interface 1 10/100Mbps Ethernet

IP Address	<input type="text"/>	(current value = 10.224.2.85 )
Subnet Mask	<input type="text"/>	(current value = 255.255.0.0 )
RARP	<input checked="" type="checkbox"/>	(current value = enabled )
BOOTP	<input checked="" type="checkbox"/>	(current value = enabled )
DHCP	<input type="checkbox"/>	(current value = disabled )
DNS	<input type="checkbox"/>	(current value = disabled )
PERSIST DHCP	<input type="checkbox"/>	(current value = disabled )

**Figure 2. TCP/IP Network Configuration for Wired Ethernet**


### Network Addressing

The two edit fields contain the NIC's IP address and subnet mask. The check boxes enable the RARP, BOOTP, DHCP, DNS, and Persistent DHCP protocols, which are alternate methods of assigning IP addresses. To use a static IP address, enter a permanent IP address and subnet mask and disable RARP, BOOTP, and DHCP. However, if your network requires use of BootP or DHCP, be sure to clear the IP address (and possibly the subnet mask) fields and ensure that the appropriate check box is selected.



The screenshot shows a window titled "Routing". Inside, there is a section for "Default Route" associated with "Interface 1". Below this, there is a "Gateway" label followed by an empty text input field. To the right of the input field, the text "(current value = 10.224.1.254 )" is displayed.

**Figure 3. Defining a Gateway Address for Ethernet Routing**



The screenshot shows a window titled "Static Route 2". It contains three rows of configuration fields: "Destination" with an empty input field, "Mask" with an empty input field, and "Gateway" with an empty input field.

**Figure 4. TCP/IP Static Routes**

## Chapter 3 Network Configuration

---

### Routing

The routing table tells the NIC which router or gateway to use to access other subnets or hosts. In most situations, you can simply add your router's IP address as the default router. All packets destined for other subnets will be forwarded to the default router for delivery to the destination host. If you have more complex routing requirements, add static routing entries for specific hosts or networks in the remaining Routing rows. Packets with IP addresses that match a given Destination and Mask (from the first two fields in a Routing row) will be routed to the router/gateway named in the third field. Packets which do not match any of the listed Destinations and Masks will be routed to the default router if one is set.

## Print Path Configuration

The NIC print path is the path a print job takes when it reaches the network adapter. First the job goes to a destination/queue (e.g. d1prn) where it then passes through an associated model (e.g. m1) for extra processing and logpath (e.g. l1) for job and printer logging. Finally the job reaches the NIC's I/O port (e.g. PRN) where it passes through to the attached printer. The "Print Path" form displays one destination's settings at a time. From here, you can then select another destination or you can go directly to an I/O port to configure port settings.

## Destination Settings

Destination Settings

### Destination Settings: d1prn

**Name:**

**BackChannel:**  prn  
 none

**Services:**  socket  
 lpd  
 lpsched  
 netbios  
 ftpd

**Selected Model:**  m1  
 m2  
 m3  
 m4  
 m5  
 m6  
 m7  
 m8

**Figure 5. Print Path Configuration, Destination Settings**

## Chapter 3 Print Path Configuration

---

### Name

Name of the destination. The default destination queue names are d1prn, d2prn, d3prn, d4prn, d5prn, d6prn, d7prn, and d8prn.

### Back Channel

I/O port to receive printer feedback when a print job passes through this destination. By default, the backchannel for all print queues is enabled for ETHERNET and WLAN.

### Services

Define what type(s) of print services the destination will support. By default all services enabled.

Parameter	
socket	Printing to a TCP port number (e.g. 9100) on the NIC
lpd	Remote printing using the Line Printer Daemon
lpsched	System V printing using the "lp" command
netbios	Printing from Windows stations relying on NetBIOS over TCP/IP
ftpd	printing using the File Transfer Protocol (FTP)

### Selected Model

Defines the model configuration that is to be associated with the current destination. The default model names are m1, m2, m3, m4, m5, m6, m7, and m8.


---

## Current Model Settings

---

### Current Model Settings

---



**Figure 6. Print Path Configuration, Current Model Settings, Model Type**

#### **Model Type**

The option is available on the Print Model web page. For a description, see page 40.

## Chapter 3 Print Path Configuration

Banner Page

### Banner Page

**Type:** none

**Position:** before

**Filter:** None selected

**Header String:** None selected

**Trailer String:** None selected

**Printer Configuration:** None

**Selected Log Path:**
 I1  
 I2  
 I3  
 I4  
 I5  
 I6  
 I7  
 I8

**Log Path Type:** None selected

**Log Path Port:** None selected

**Figure 7. Print Path Configuration, Current Model Settings, Banner Page**

### Banner Page

The option is available on the Print Model web page. For a description, see page 41.

### Filter

The option is available on the Print Model web page. For a description, see page 41.

---

## Current Model Settings

### **Header String**

The option is available on the Print Model web page. For a description, see page 41.

### **Trailer String**

The option is available on the on the Print Model web page. For a description, see page 41.

### **Printer Configuration**

The option is available on the Print Model web page. For a description, see page 42.

### **Selected Log Path**

This option defines the log path configuration that is to be associated with the current destination.

### **Log Path Type**

The option is available on the Log Path web page. For a description, see page 43.

### **Log Path Port**

The option is available on the Log Path web page. For a description, see page 44.

## Chapter 3 Print Model Configuration

### Print Model Configuration

Model Settings: m1

---

**Model Settings: m1**

**Name:**

**Model Type:**  raw

**Banner Page:** Type:  none  text  
 Position:  before  after

**Filter:**  insert carriage return after line feed

**Header String:**

**Trailer String:**

**Printer Configuration:**

**Figure 8. Print Model Configuration, Model Settings**

#### Name

Name of the model. The default model names are m1, m2, m3, m4, m5, m6, m7, and m8.

#### Model Type

Define what processing (if any) will be performed on print jobs passing through the associated destination. If set to "raw", the job will not be touched by the network adapter.

---

## Banner Page

Tells the Ethernet Interface to produce a banner page with each print job. The type of banner page data can be text. You can also specify whether the banner page should come at the front or the end of a print job.

## Filter

Specify whether the Ethernet Interface is to add carriage returns to print jobs passing through that contain solitary linefeeds. This is common with Unix text jobs resulting in stair-stepped output.

## Header String

Define an escape sequence to be sent to the printer before each print job. For example, you may want to send a sequence to print the job in landscape mode or to a certain tray on the printer. You can specify up to four separate sequences per header string. The Ethernet Interface will execute them in order from top to bottom. If specifying fewer than four sequences, be sure to start at the top leaving undefined fields at the bottom.

**NOTE:** You can specify up to four separate sequences per header string. The Integrated PrintNet Enterprise will execute them in order from top to bottom. If specifying fewer than four sequences, be sure to start at the top leaving undefined fields at the bottom.

## Trailer String

Define an escape sequence to be sent to the printer after each print job. For example, you may want to send a sequence to add a formfeed so you don't have to manually press the formfeed button on the printer. You may also want to tell the printer to reset itself in case you have set a header string which tells the printer to do something special with the job. You can specify up to three separate sequences per trailer string. The Ethernet Interface executes them in order from top to bottom. If specifying fewer than four sequences, be sure to start at the top leaving undefined fields at the bottom.

## Chapter 3 Print Model Configuration

---

The most common sequence is listed on the form:

- **Formfeed** - tells the printer to do a formfeed at the end of the data.

### Printer Configuration


Specify a printer configuration number to be loaded before processing the print job. This ability to associate a printer configurations to a logical printer model allows you to define up to eight unique and independent printer personalities in a single printer. Using this feature, you effectively have eight different printers in one.

To associate a printer configuration to the currently selected destination queue, just select the desired printer configuration number from the drop down list. Once a printer configuration has been associated with a destination queue, any print job sent to that destination queue name will cause the printer to load the associated printer configuration before processing the print job.

---

## Log Path Configuration

---



The screenshot shows a window titled "Log Path Settings: I1". Inside, there is a section titled "Log Path Settings: I1". Below this, there are three main settings:

- Name:** A text input field containing "I1".
- Logpath Type:** A list of checkboxes:
  - job
  - user
  - i/o port
  - checksum
  - printer
- Logpath Port:** A list of radio buttons:
  - pm
  - none
  - TCP/IP Port:  (e.g. 4010)
  - syslog:
  - email:

**Figure 9. Log Path Settings**

### Name

Name of the log path. The default names are I1, I2, I3, I4, I5, I6, I7, and I8.

### Logpath Type

Define what type of log information will be tracked for each print job passing through the associated destination. The types are:

- **job** - job ID, username, etc.
- **user** - user ID and three messages per job about the start and finish
- **checksum** - value used when troubleshooting integrity of data transferred
- **printer** - miscellaneous messages from the printer
- **i/o port** - status of the printer based on the port interface signals.

## Chapter 3 Log Path Configuration

---

### Logpath Port

Define where logging information for print jobs passing through the associated destination will be reported. The choices are:

- **prn** - reported to the PRN port
- **none** - don't report any logging information
- **TCP/IP port** - to a TCP port number (specified in the edit field)
- **syslog** - to a host (specified by the IP address in the edit field) running a SYSLOG daemon
- **email** - to an e-mail address (specified by the e-mail address and the SMTP server IP address edit fields). You can set the option on the Administration web page.

*Default:* no logging turned on.

---

## SNMP Configuration

---

The SNMP Configuration form allows you to configure SNMP trap managers and the e-mail alert features of NIC. It allows you to configure how SNMP alerts are processed by a SNMP trap manager, a Unix syslog logging daemon, and/or have e-mail notifications sent. Up to 10 SNMP trap managers and e-mail recipients may be specified. Individual alerts fall into one of 14 alert group categories, providing the ability to filter alert notices as desired.

### SNMP Manager Alert Posting Settings

**Alert Posting Configuration 1:**

SNMP Manager Alert Posting  Enabled

SNMP Manager IP Address:

UDP Port:

Community Name:

**Figure 10. SNMP Manager Alert Posting Configuration**

Specifies whether alerts from the enabled alert group categories for this configuration will be sent to the SNMP manager. If this option is enabled, the following information must be entered:

- **SNMP Manager IP Address** - specifies the IP address of the SNMP trap manager
- **UDP Port** - specifies the UDP port number used by the SNMP trap manager for receiving trap messages. Acceptable values are 162, and 49152 through 65535
- **Community Name** - up to 15 character string specifying the trap community name.

## Chapter 3 SNMP Configuration

### Syslog Alert Posting Settings




The form shows a section titled "Syslog Alert Posting" with a checkbox labeled "Enabled" that is currently unchecked.

**Figure 11. SNMP Syslog Alert Posting Configuration**

Specifies whether alerts from the enabled alert group categories for this configuration will be sent to the Unix syslog daemon. If this option is enabled, the syslog daemon IP address must be entered in the syslog field in the System Information section of the Administration Configuration form.

Default: Disabled

### E-mail Alert Posting Settings



The form shows a section titled "Email Alert Posting" with several settings:

- Enabled:
- Email Address:  (e.g., username@domain.com)
- Short Email Format:
- Short Email Message Length:
- Send Test Message:

**Figure 12. SNMP Email Alert Posting Configuration**

---

Specifies whether alerts from the enabled alert group categories for this configuration will be sent to the specified e-mail address. If this option is enabled, the following information must be entered:

- **E-mail Address** - specifies an e-mail address to which alert information will be sent
- **Short E-mail Format** - specifies whether a short (15-80 character) alert e-mail message should be sent.

If enabled, the message will contain the alert description, the severity level, device description, and device name (unless the length of the message exceeds the Short E-mail Message Length, in which case the message will be truncated).

If disabled, the message will contain additional information including the device description, device name and location, alert description, alert group, alert severity level, and printer status.

*Default:* Disabled

- **Short E-mail Message Length** - Specifies the maximum size of the short e-mail message. Acceptable values are 15 to 80 characters.

*Default:* 80 characters

- **Send Test Message** - Provides a way to test the validity of the e-mail address/SMTP server address. If checked, a test message will be sent to the specified e-mail address when the submit button is pressed.

If the alert message is to be sent to a cellular phone or pager, the Short E-mail Format option should be enabled. Once this option is enabled, you may specify the maximum e-mail message length (15-80 characters). When enabled, the message will contain the alert description, the severity level, device description, and device name (unless the length of the message exceeds the Short E-mail Message Length, in which case the message will be truncated).

If the Short E-mail format is disabled, the message will contain additional information including the device name and location, alert description, alert group, alert severity level, and printer status.

## Chapter 3 SNMP Configuration

To test the validity of the e-mail address and the SMTP server address, enable the Send Test Message option. If the Send Test Message box is checked, a test message will be sent to the specified e-mail address when the submit button is pressed.

### Alert Groups

Alert Groups

---

**Alert Groups (check to enable):**

**Warning Alerts:**

**Offline Alerts:**

**Media Input Alerts:**

**Media Output Alerts:**

**Media Path Alerts:**

**Marker Alerts:**

**Figure 13. SNMP Alert Groups Configuration**

Specifies which alert groups are enabled for reporting for this configuration. When an alert occurs that is contained in one of the enabled alert groups, it will be posted to the specified SNMP manager, Unix syslog daemon, and/or e-mail address. The following table describes which printer events belongs to which Alert Group.

---

*Default:* All alert groups are enabled by default.

**Table 1. Alert Groups and Printer Events**

<b>Alert Group</b>	<b>Printer Events</b>
Warning	File System Full File Exist Half Speed Mode
Offline	Printer is Offline
Media Input	Load Paper Paper Jam
Media Path	Clear Paper Jam
Marker	Shuttle Over Speed
Barcode	Barcode Fail Specification Barcode Quiet Zone Too Small Barcode Improper Data Format
Consumable	Ribbon Low

**NOTE:** Not all of the alerts are available on all of the printers. The alerts available for monitoring will depend on the printer type and the options installed on the printer.

## **Administration Configuration**

---

The Administration Configuration form is broken down into general print server-related settings and password security.

## Chapter 3 Administration Configuration

### System Information

System Information

**NOTE:** Changes in server name setting only take effect after you reset the Integrated PrintNet Enterprise from the System page.

**Name:**

**Description:**

**Location:**

**Contact:**

**Printer Serial Number:**

**Syslog:**  (e.g., 204.191.175.114)

**Email:**  (e.g., username@domain.com)

**SMTP server:**  (e.g., 204.191.175.114 or smtp.domain.com)

**DNS server:**  (e.g., 204.191.175.114)

**Figure 14. Administration Configuration, System Information**

The System Information form allows you to specify the following information about the printer:

#### **Name**

Name given to the print server in Windows environment. The default name is "P\_XXXXXX" where "XXXXXX" equals the last six digits of the NIC's Ethernet address. (e.g. P\_01001C).

#### **Description**

Optional field to help identify the printer's features and capabilities.

---

## System Information

### Location

Optional field to help identify the printer's physical location.

### Contact

Optional field to help identify the individual or group responsible for the printer.

### Printer Serial Number

Allows the user to enter the printer serial number. The field is blank by default.

**NOTE:** If the user has not entered a serial number through one of the NICs, depending on the printer type, the printer may use its internal serial number from EEPROM. If EEPROM is blank, i.e. no serial number on the board, it will use the MAC address of the embedded NIC, embedded wireless NIC, or external NIC, respectively, as the printer's serial number.

### Syslog

Specifies the IP address of a host running the SYSLOG daemon. NIC debugging or printer logging information can be sent to the IP address.

### Email

Defines the user email address to receive printer and job logging information from log paths on the NIC.

Default: Unconfigured (empty).

### SMTP Server

Specifies the IP address or domain name of the SMTP server to be used for processing email messages generated by the NIC.

Default: Unconfigured (empty).

## Chapter 3 Administration Configuration

### DNS Server

Specifies the IP address of the domain name server to be used for resolving host names (e.g. host.domain.com) to IP addresses (e.g. 192.168.0.42).

Default: Unconfigured (empty).

**NOTE:** If the DNS server field is initially blank, the NIC will automatically use the IP address of the DNS server and enter it in the DNS server field when DHCP is enabled.

### Passwords

Passwords

**NOTE:** Reauthorization is necessary after changing a password.

Root Password

Old:

New:

Confirm:

Guest Password

Old:

New:


Confirm:

**Figure 15. Administration Configuration, Passwords**

Only a user with root privileges can alter the NIC's settings. Guest users can only view settings but cannot alter them. Both types of users can be assigned passwords. To change a password, type in the old password in the "Old" field. Then type the new password twice: once in the "New" field, and once in the "Confirm" field.

*Default:* No passwords for root or guest users.

## System Configuration



**Figure 16. System Configuration**

The System Configuration form allows you to change the NIC 's operation mode. Select "Reboot" to re-power the print server. Select "Default" to reset the print server and have it come up with factory default settings.

## Status

The Status menu items allow you to view the current status of both the printer and the network. The submenu items available are as follows:

- **I/O Port** - this menu item allows you to view the current status of the printer, including the print jobs that are queued or are currently active.
- **Network** - this menu item allows you to view the current status of the network connection.

## Chapter 3 Status - I/O Port

---

### Status - I/O Port

---

The I/O Port Status form allows you to remotely see what is happening on the NIC I/O port. The port's status and a list of active and queued jobs will be displayed. You can cancel a job (as long as you have permission) by clicking the Cancel icon beside the desired job. If you see "waiting" in the "Status" line, this indicates the network adapter is either waiting for data from the host or for feedback from the printer. If you see "blocked" in this line, this indicates the printer is not allowing the NIC to send any more data. The printer could be busy processing data it has already received or it could be in an error state.

The printer status display is automatically refreshed every minute.

The printer's buffer size may not allow you to monitor the real time status of the printer and the print job at the same time. The status feedback to the host usually reads "printer idle" unless the print job is significantly large.

### Status - Network

---

This form allows you to view the current status of the network. The statistical data provided is broken down by network protocol. You can use this form to troubleshoot network-related problems.

### Help

---

General help information is available online. It provides assistance with the configuration and status reference for the Integrated PrintNet Enterprise network adapter. Through the provided HTML forms, you can configure settings on the Integrated PrintNet Enterprise and view printer status.

---

# 4

## *Windows Configuration*

### Overview

---

This chapter details a complete Windows configuration setup including:

- Identifying the NIC on the network using TCP/IP as the underlying protocol
- Configuring the NIC with its mandatory TCP/IP settings (IP address and subnet mask)
- Configuring a new printer on the Windows station

### Windows Environment Description

---

The NIC supports network printing under Windows environments by using TCP/IP. In a Windows NT<sup>®</sup>/Vista<sup>®</sup> setup, pure TCP/IP is used as the network protocol whereas with Windows 95/98<sup>®</sup>, Windows Me<sup>®</sup>, NetBIOS is used over TCP/IP.

## Chapter 4 Windows NIC Configuration

---

### Windows NIC Configuration

---

The IP address and subnet mask are mandatory TCP/IP settings and are needed before the print server can be detected on the network. There are also additional optional settings. This section offers alternative methods for configuring your NIC in a Windows environment and describes some of the more common optional settings available.

#### Mandatory

---

Since TCP/IP is used for Windows printing, the NIC must be configured with a minimum of an IP address and subnet mask before it can be seen on the network.

#### Optional

---

Additional settings, like routing entries, can be configured. This allows communication across subnets when no other router exists.

You can configure the NIC done from the printer control panel, Web browser, host commands, or other utility software. To configure these options, see “Configuration Tools” on page 21.

#### Configuration Using ARP

---

To configure the NIC with its IP settings using a manual `arp` command:

1. Log on to a Windows station with TCP/IP loaded and located on the same subnet as the NIC.
2. Find the Ethernet address for the NIC on the configuration printout. It must be entered as part of this procedure.

---

## Configuration Using ARP

3. Use the `arp` command to add an entry into the Windows station ARP table for the NIC. This is the most common syntax for this command:

Syntax:

```
arp -s ipaddress ethernetaddress
```

Example for Microsoft® TCP stacks:

```
arp -s 192.75.11.9 00-08-96-07-00-60
```

This example specifies a NIC using IP address 192.75.11.9 and Ethernet address 00-08-96-07-00-60.

4. Check if the ARP entry was accepted.

```
arp -a
```

You should see an entry in the listed ARP table with the IP address and Ethernet address specified in Step 3.

5. Ping this IP address to see if the NIC can be seen on your network.

At this point, you should be able to communicate with the NIC from your local Windows station. This means the print server knows about an IP address and subnet mask and has these settings in its current memory. However, if the NIC is power cycled, these settings will disappear unless you store them into flash memory. To do this:

- a. Load a Web browser on your Windows station and direct it to the URL:

```
http://NICIPaddress/networkConf.html
```

(e.g., `http://192.75.11.9/networkConf.html`).

**NOTE:** If prompted for a “User ID” and password first, type `root` for the ID and press ENTER at the password prompt (since there is no password by default).

- b. At the “Network Configuration” HTML form that displays, click in the field below the “IP Address” heading and type in the IP address for the NIC.

## Chapter 4 Windows NIC Configuration

---

- c. Under the “Subnet Mask” heading, enter the NIC subnet mask.

**NOTE:** If you would like to communicate with the NIC from across routers, you will need to fill in an entry within the “Routing” section. Please see “Communicating Across Routers” on page 58 for more details.

6. Click on the SUBMIT button when done and physically repower the printer to make the new settings take effect.

### Communicating Across Routers

---

Since Windows environments rely on TCP/IP to communicate with the NIC, crossing routers becomes an issue.

After you have followed one of the NIC configuration methods mentioned, most likely you will only be able to communicate with the print server from the same subnet. This means any hosts across a router will not be able to see your NIC. In order for hosts across a router to see your NIC, store a default router/gateway within the print server so that any packets destined for another subnet get forwarded to this router automatically. The router (or series of routers) can then take over, ensuring the packets get to their final destination on another subnet on your network.

To configure a default router/gateway within the NIC:

1. Load a Web browser on your Windows station and direct it to the URL:

`http://NICIPaddress/networkConf.html`  
(e.g., `http://192.75.11.9/networkConf.html`).

**NOTE:** If prompted for a “User ID” and password first, type in `root` for the ID and press ENTER at the password prompt (since there is no password by default).

2. At the “Network Configuration” HTML form that displays, click in the first field below the “Gateway” heading and type in the IP address of the default router/gateway for the NIC subnet.

---

## Changing Workgroup Names

---

3. Click on the SUBMIT button when done and physically repower the print server to make the new settings take effect.

## Changing Workgroup Names

---


Windows environments define groups of related computers as “workgroups.” By default, “WORKGROUP” is the name that is assigned to the NIC workgroup. However, you may want to change this to suit your network better. To do this:

1. Load a Web browser on your Windows station and direct it to the URL:  
`http://NICIPaddress/networkConf.html`  
(e.g., `http://192.75.11.9/networkConf.html`).
- NOTE:** If prompted for a “User ID” and password first, type in `root` for the ID and press ENTER at the password prompt (since there is no password by default).
2. At the “Network Configuration” HTML form that displays, search for the “Windows (NetBIOS TCP/IP)” section and highlight the “Workgroup Name” field.
3. Type in the new workgroup name for the NIC.
4. Click on the SUBMIT button when done and physically repower the print server to make the new settings take effect.

## Chapter 4 Windows NIC Configuration

### Changing Destination Names

When defining some printers within Windows environments, the NIC requires that you specify a predefined destination rather than any name you would like. For example, when creating a new printer under Windows NT, a screen similar to Figure 17 displays.



**Figure 17. Windows NT Print Setup Dialogue Box**

The first field requires the IP address for the NIC, and the second field must be filled in with a valid destination from the print server (e.g., d1prn). Otherwise, LPR will not be able to access the printer. Table 2 outlines the default destinations to choose from.

**Table 2. NIC Default Destinations**

Destination	Mapped I/O Port
d1prn	PRN
d2prn	PRN
d3prn	PRN
d4prn	PRN
d5prn	PRN
d6prn	PRN
d7prn	PRN
d8prn	PRN

---

## Changing Destination Names

This name can be changed to something more meaningful using the built-in HTML forms. To do this:

1. Load a Web browser on your Windows station and direct it to the URL:

**`http://NICIPaddress/destConf.html`**

(e.g., `http://192.75.11.9/networkConf.html`).

**NOTE:** If prompted for a “User ID” and password first, type in **root** for the ID and press ENTER at the password prompt (since there is no password by default).

2. At the “Print Path Configuration” HTML form that displays, select a destination link from the top of the page to bring up the appropriate destination form. By default, you should see a line near the top of the form showing the destinations listed in Table 2.
3. Once the desired destination HTML form displays, highlight the “Name” field and type in the new name for this destination.
4. Click on the SUBMIT button when done and physically repower the print server to make the new setting take effect.

## Chapter 4 Windows Host Configuration

### Windows Host Configuration

This section covers Windows Vista, XP, 2000, and 2003 Server printer setup.

#### Printer Driver Setup Wizard


1. Select Windows Drivers from the CD. The Printer Driver Setup Wizard window displays.



**Figure 18. Setting Up the Printer Driver**

2. Click **Next**. The Welcome to the Add Printer Wizard window displays.
3. Click **Next**.
4. Select the type of printer to set up and click **Next**. For this example, select **Local printer attached to this computer**.

## Printer Driver Setup Wizard



**Figure 19. Selecting a Printer Port**

5. Select a port for the printer to use and click **Next**. For this example, select **LPT1:(Recommended printer Port)**.

## Chapter 4 Windows Host Configuration



**Figure 20. Selecting a Printer Driver**

6. Select the printer driver and click **Next**.
7. Enter a printer name and specify whether to have this printer set up as the default printer, then click **Next**. For this example, select **No**. By default the printer you selected in the previous step is entered.
8. Select **Do not share this printer** and click **Next**. You are prompted to print a test page.
9. Select **No** and click **Next**.

## Printer Driver Setup Wizard

---



**Figure 21. Printer Driver Installation Completion**

10. Click **Finish** to complete the add printer wizard.
11. Click **Finish**. You have successfully installed your printer driver. Next the printer setup wizard will guide you through basic printer setup.

## Windows Driver Usage Information

---

Refer to the online help file for important Windows driver usage information, restrictions, and limitations. Online help information is available in the driver properties dialog box.

**Chapter 4** Windows Driver Usage Information

---

---

# 5

## *Unix Configuration*

### Overview

---

This chapter details a complete Unix setup including:

- Configuring the NIC with its mandatory TCP/IP settings (e.g., IP address and subnet mask).
- Configuring the Unix host station with a new printer.

### Unix Environment Description

---

The NIC supports network printing under various TCP/IP environments including all variations of Unix. Printing can come from multiple hosts directly or through central spooling machines.

## Chapter 5 Unix NIC Configuration

---

### Unix NIC Configuration

---

There are mandatory settings needed before the print server can be detected on the network, as well as some additional optional settings. This section offers alternative methods for configuring your NIC and mentions some of the more common optional settings available.

#### Mandatory

---

Since TCP/IP is used, the NIC must be configured with a minimum of an IP address and subnet mask before it can be seen on the network. To configure these options, see “Configuration Tools” on page 21.

#### Optional

---

Additional settings, like routing entries, can be configured allowing for communication across subnets.

Configuration of the NIC can be done from the control panel or through host commands. To configure these options, see “Configuration Tools” on page 21.

#### Using ARP

---

To configure the Ethernet Interface with its TCP/IP settings using a manual `arp` command, the syntax is:

```
arp -s ipaddress ethernetaddress
```

For the `aix` command, the syntax is:

```
aix -s ether ipaddress Mac_address
```

To use either of these commands:

1. Log on to a Unix station as **superuser** or **root**. This station must be located on the same subnet as the NIC since ARP is limited to subnets.

---

## Using ARP

2. Find the Ethernet address for the NIC by printing a configuration or reading it from the control panel. It must be entered as part of this procedure.
3. Use the `arp` command to add an entry into the Unix station ARP table for this NIC. Here is the most common syntax for this command:

```
arp -s ipaddress ethernetaddress
```

Example for Microsoft TCP stacks:

```
arp -s 192.75.11.9 00:08:96:07:00:60
```

This example specifies a NIC using IP address 192.75.11.9 and Ethernet address 00:08:96:07:00:60.

4. Verify that the ARP entry was properly applied.  

```
arp -a
```

You should see an entry in the listed ARP table with the IP address and Ethernet address specified in step 3.
5. Try to `ping` this IP address to see if the NIC can be seen on your network.

At this point, you should be able to communicate with the NIC from your local Unix station. This means the printer knows about an IP address and subnet mask and has these settings in its current memory. However, if the NIC is shut off, these settings will be lost unless you store them in flash memory, as follows:

1. Load a Web browser on your Windows station and direct it to the URL:

```
http://NICIPaddress/networkConf.html
```

(e.g., `http://192.75.11.9/networkConf.html`).

- NOTE:** If prompted for a “User ID” and password first, type in `root` for the ID and press ENTER at the password prompt (since there is no default password).
2. At the “Network Configuration” HTML form that displays, click in the field below the “IP Address” heading and type in the IP address for the NIC.

## Chapter 5 Unix NIC Configuration

---

3. Under the **Subnet Mask** heading, enter the NIC subnet mask.

**NOTE:** If you would like to communicate with the NIC from across routers, you will need to fill in an entry within the “Routing” section. Please see “Communicating Across Routers” on page 72 for further details.

4. Click the **Submit** button when done and physically repower the print server to make sure the new settings are in effect.

### Using RARP

---

RARP allows you to dynamically assign an IP address to the NIC upon bootup. To configure the NIC with its TCP/IP settings using RARP:

1. On your RARP server, make an entry in the `/etc/ethers` file for the NIC.

Syntax:

```
ethernetaddress NICIPaddress
```

Example:

```
00:08:96:07:00:60 192.75.11.9
```

2. Start the RARP daemon on the RARP server if not already running. If it is running, send an HUP signal to it with the `kill` command:

Syntax:

```
kill -HUP pid
```

where *pid* is the process ID of the RARP daemon.

3. Power on the NIC so that it immediately sends out an RARP request. Wait one minute to allow the address assignment process to complete. You should see the STAT LED on the NIC interface slow down, indicating it knows about an IP address to use.

---

## Using BOOTP

4. Try to `ping` the NIC IP address from a local Unix station to see if it can be seen on your network.

**NOTE:** You will only be able to communicate with the NIC from a network station on the same subnet as the print server. The NIC needs to be told about a default router/gateway so any packets that come in from a different subnet can be returned via this gateway. Please see “Communicating Across Routers” on page 72 to set this up.

---

## Using BOOTP

BOOTP allows you to dynamically assign an IP address to the NIC upon startup. In addition, the BOOTP server can provide additional details like a default router/gateway address. To configure the NIC with its TCP/IP settings using BOOTP:

1. On your BOOTP server, make an entry in the `/etc/bootptab` file for the NIC.

Syntax:

```
NICIPname: \  
:sm=netmask: \  
:hd=homedirectory: \  
:bf=null: \  
:gw=defaultgateway: \  
:ht=ethernet: \  
:ha=ethernetaddress: \  
:ip=ipaddress: \  
:ts=timeserver: \  
:to=timezone:
```

Example:

```
spike: \  
:sm=255.255.255.0: \  
:hd=/usr/null: \  
:bf=null: \  
:gw=192.75.11.1: \  
:ht=ethernet: \  
:ha=000896070060: \  
:ip=192.75.11.9: \  
:ts=192.75.11.7: \  
:to=25200:
```

## Chapter 5 Unix NIC Configuration

---

2. Turn the NIC on so that it immediately sends out a BOOTP request. Wait one minute to allow the IP address assignment process to complete.
3. Try to `ping` the NIC IP address from a network station to see if it can be seen on your network.

**NOTE:** You will be able to communicate with the NIC from network stations on different subnets if the print server has been told about its default router/gateway in the BOOTP response from the BOOTP server.

### Communicating Across Routers

---

Since Unix environments rely on TCP/IP to communicate with the NIC, crossing routers becomes an issue.

After you have followed one of the NIC configuration methods mentioned (other than the BOOTP method), most likely, you will only be able to communicate with the print server from the same subnet. This means any host across a router will not be able to see your NIC. In order to communicate across a router, store a default router/gateway within the print server so that any packets destined for another subnet get forwarded to this router automatically. The router (or series of routers) can then take over the process of ensuring the packets get to their final destination on another subnet on your network.

To configure a default router/gateway within the NIC:

1. Load a Web browser on your Windows station and direct it to the URL:  
`http://NICIPaddress/networkConf.html`  
(e.g., `http://192.75.11.9/networkConf.html`).

**NOTE:** If prompted for a User ID and password first, type in `root` for the ID and press ENTER at the password prompt (since there is no default password).

2. At the **Network Configuration** HTML form that displays, click the first field below **Gateway** and type in the IP address of the default router/gateway for the NIC subnet.

---

## Manual System V Host Setup

---

3. Click **Submit** when done and physically repower the print server to make sure the new setting is in effect.

## Unix Host Configuration

---

There may be times when you would prefer or have to perform the manual setup steps for a new printer definition. There may also be times when you require a less common print solution such as direct socket capabilities. This section covers these additional setups.

### Manual System V Host Setup

---

This setup involves any Unix operating system using System V print spooling (e.g., SCO, Solaris<sup>®</sup>, HP-UX<sup>®</sup>, DG/UX<sup>®</sup>, etc.). This means an interface file is used for each defined printer and, in the case of any System V print setup involving a NIC, the RSHD protocol is used to transfer data from the host to the print server.

To manually configure a new System V printer on a Unix station, create a dummy device file that acts as a locking mechanism between contending print jobs.

Syntax:

```
touch /dev/NICname.portname
```

where *NICname* is the host or IP name of the print server and *portname* is one of its four I/O ports.

Example:

```
touch /dev/spike.prn
```

## Chapter 5 NIC Installation on HP-UX

---

### NIC Installation on HP-UX

---

LPR is supported in HP/UX Version 9.0 and greater. To configure a print queue using LPR, issue the following commands.

**NOTE:** Requires root privilege. The default BSD interface file “rmodel” will be used.

Syntax:

```
lpshut
lpadm -pqueue_name -mmodel -v/dev/null
      -orm[printer_ip] -orpd1prn -ob3
lpsched
accept queue_name
enable queue_name
```

queue\_name = any unique printer name

[printer\_ip] = IP address of the printer or the DNS name (without brackets)

d1prn = NIC remote printer name\*

**Explanation of command line:**

-m indicates the model rmodel

-v indicates the use of /dev/null as a file interlock to avoid contention

-orm is the name of remote Print Server

-orp is the name of the remote printer on the remote Print Server

-ob3 declares that the remote Print Server is a BSD type

**NOTE:** The “lpshut” command stops the HP spooling system; do not perform when print jobs are active.

The default NIC destination name is d1prn, however, this name can be changed. To verify the queue name, print an Ethernet Test Page or telnet to the adapter and run a “list dest” command.

To print to this queue, use normal lp syntax:

```
# lp -dqueue_name filename
```

## Solaris 2.6 – 7 NIC Setup

---

**NOTE:** Requires Superuser privilege in the borne shell. Assume that you can ping and Telnet to the adapter.

The IP address of the NIC must be placed in the `/etc/hosts` file.

Syntax:

```
lpadmin -p [queue_name] -v /dev/null
lpadmin -p [queue_name] -i /usr/lib/lp/model/
netstandard
lpadmin -p [queue_name] -o dest=[host_name] -o
protocol=bsd -o timeout=60
lpadmin -p [queue_name] -s [host_name]!d1prn -I any
enable {queue_name}
accept [queue_name]
```

where

[queue\_name] = any name, but not the name in the `etc/hosts` file or `d1prn`

[host\_name] = name in `etc/hosts` file

### Troubleshooting

This installation procedure assumes that the NIC is configured with the correct IP address, subnet mask, and gateway address (if required). You can also ping and telnet to the NIC.

Print an E-Net Test Page to verify the Ethernet settings.  
See “Printing A NIC Test Page” on page 22.

The default NIC queue name is `d1prn`, however, the name can be changed. To verify the queue name, print an E-Net Test Page or telnet to the NIC and run a “list dest” command.

**NOTE:** Depending on the shell, precede the `!` character with a `\` to avoid shell script errors.

## Manual LPR/LPD Host Setup

---

The NIC also supports Unix operating systems which follow a BSD print system (e.g., SunOS 4.1.x). This means a printcap file is used to define all printers available on the host, and interface scripts are not commonly used. Instead, LPR/LPD printers are defined.

To manually configure an LPR/LPD printer on a BSD Unix system:

1. Define an entry for this new printer within the printcap file, /etc/printcap.

Syntax:

```
printername:  
:sh:pw#80:mx#0:\  
:rm=NICname:\  
:rp=NICdestination:\  
:lp:\  
:sd=/usr/spool/lpd/printername\  
:lf=/usr/spool/lpd/printername/log:\  
:af=/usr/spool/lpd/printername/acct:
```

where *printername* is any name you would like to give to this new printer, *NICname* is the host or IP name of the print server, and *NICdestination* is one of the pre-defined destinations/queues on the device.

Example:

```
6600:  
:sh:pw#80:mx#0:\  
:rm=spike:\  
:rp=dlprn:\  
:lp:\  
:sd=/usr/spool/lpd/ 6600:\  
:lf=/usr/spool/lpd/ 6600/log:\  
:af=/usr/spool/lpd/ 6600/acct:
```

2. Create the spool directory specified by the *sd=* entry in the printcap entry for this printer.

Example:

```
touch /usr/spool/lpd/ 6600
```

3. Create the log and account files specified by the *lf=* and *af=* entries in the printcap entry for this printer.

---

## Manual LPR/LPD Host Setup

Example:

```
touch /usr/spool/lpd/6600/log
touch /usr/spool/lpd/6600/acct
```

4. Change permissions and ownership on the spool directory and everything within it.

Example:

```
chmod -R g+rwX,o+rX /usr/spool/lpd/ 6600
chmod -R daemon.daemon /usr/spool/lpd/ 6600
```

5. Start the printer daemon for this new printer.

Example:

```
lpc start 6600
```

You now have a new printer which relies on LPR/LPD to print to a NIC printer. Use the following command to test printing:

Syntax:

```
lpr -P printername filename
```

Example:

```
lpr -P 6600 /etc/hosts
```

## Printing With FTP

---

Print jobs can also be sent to the NIC using the File Transfer Protocol (FTP). To do this:

1. On your network station, change to the directory containing the file you want to print.

2. Open an FTP session with the NIC.

Syntax:

```
ftp NICIPaddress
```

3. Log in as `root`.
4. At the password prompt, press ENTER (since there is no default password).

5. Change to the `dest` directory.

Syntax:

```
cd dest
```

6. List the contents of this directory using the `dir` command and determine which destination/queue you would like to send the print job through. Most likely, you will select `dlprn` for the PRN port.

7. Change to this destination directory.

Example:

```
cd dlprn
```

8. Change the mode to correspond with the type of file you are going to print. By default, ASCII is set for text-only files, but if you need to print both text and graphics, select binary using the `bin` command.

9. Place the file to be printed within this directory on the NIC, so it can be spooled and printed.

Syntax:

```
put filename
```

## Direct Socket Printing

---

10. Close the FTP session, unless you have more jobs to print.

Syntax:

```
quit
```

## Direct Socket Printing

---

Within TCP/IP environments, there are some setups which require the host to print directly to a TCP port number on the NIC, bypassing all of the higher level destination/queue names. If you run into a setup which requires this, you will need to define two parameters for a new print setup:

1. **NIC IP address.** The IP address or host name of the print server to which you want to print.
2. **NIC TCP port number.** A pre-defined number for the I/O port on the print server. 9100 is the default port number.

Though the host will be sending directly to a TCP port number on the NIC, the port numbers are still mapped to destinations/queues in case there is some type of special processing or logging to be done to the job. However, the destination name is of no concern in this type of printer definition. Only the two parameters mentioned above need to be defined for printing to work.

**Chapter 5** Solaris 2.6 – 7 NIC Setup

---

---

# 6

## *AS/400 Configuration, ASCII Printer*

### Overview

---

This chapter details a complete AS/400 configuration setup including:

- Developing Line Descriptions with CRTLINETH
- Configuring the AS/400 for TCP/IP
- Configuring the AS/400 for Printing
- Verifying Printing from the AS/400

This document assumes no AS/400 printer configuration has been done. If any configuration has been done, please follow the procedure to the point at which continued configuration is required.

#### **Developing Line Descriptions With CRTLINETH**

For each LAN adapter on the AS/400, a line description needs to be created for the NIC. This is required for Release V3R2 and V3R7.

If a line description already exists, make sure the SSAP list includes default options “AA” and “12.” You must also know the LAN speed for the AS/400 LAN adapter.

**NOTE:** To change a line description, you need to vary the line off before making the change. After making the change, you need to vary the line back on.

To change an existing line description, use the CHGLINETH command. To create a line description, use CRTLINETH.

## Chapter 6 Overview

**NOTE:** SSAPS of “AA” and “12” are automatically set as default values in the line description when “\*CALC” is used in creating new line descriptions. You do not need to set these values unless they have been changed.

To create a line description, enter the following command:

```
CRTLINETH LIND(ETHLAN) RSRNAME(LIN041)
```

Your completed screen should look like Figure 22.

```

5763SS1 V3R2M0 960517                                BLDD60 09/11/96 12:25:46
Line description . . . . . : LIND      ETHLAN
Option . . . . . : OPTION    *ALL
Category of line . . . . . :          *ELAN
Resource name . . . . . : RSRNAME  LIN041
Online at IPL . . . . . : ONLINE  *YES
Vary on wait . . . . . : VRYWAIT *NOWAIT
Local adapter address . . . . . : ADPTADR *ADPT
Exchange identifier . . . . . : EXCHID 056A1005
Ethernet standard . . . . . : ETHSTD  *ALL
Maximum controllers . . . . . : MAXCTL  40
Error threshold level . . . . . : THRESHOLD *OFF
Text . . . . . : TEXT      *BLANK
-----Active Switched Controllers-----
(No active switched controllers attached)
SSAP list . . . . . : SSAP
-----Source Service Access Points-----
SSAP      Maximum Frame   Type          SSAP      Maximum Frame   Type
  04             1496      *SNA          AA             1496      *NONSNA
  12             1496      *NONSNA      C8             1496      *HPR
Group address . . . . . : GRPADR
-----Group Addresses-----
(No group addresses found)
Link speed . . . . . : LINKSPEED 10M
Cost/connect time . . . . . : COSTCNN 0
Cost/byte . . . . . : COSTBYTE 0
Security for line . . . . . : SECURITY *NONSECURE
Propagation delay . . . . . : PRPDLY *LAN
User-defined 1 . . . . . : USRDFN1 128
User-defined 2 . . . . . : USRDFN2 128
User-defined 3 . . . . . : USRDFN3 128
Autocreate controller . . . . . : AUTOCRTCTL *NO
Recovery limits . . . . . : CMNRCYLMT
  Count limit . . . . . : 2
  Time interval . . . . . : 5

```

Figure 22. Example NIC Line Description

---

## Configuring With ADDTCPIFC

---

The following three parameters must be specified:

### Line Description (LIND)

The line description name is the user's name for the AS/400 adapter. This name must be identical to the name entered when the TCP/IP is configured on the AS/400.

### Resource Name (RSRCNAME)

The system-assigned name for the interface (for example, LIN041).

### SSAP

When \*CALC is used, the values of "12" and "AA" are entered automatically as defaults. Verify that those SSAP values have not been changed.

## Configuring AS/400 For ASCII Using TCP/IP

---

The next step is to configure the interface on the AS/400 for TCP/IP.

**NOTE:** The AS/400 interface is not the NIC. Do not set the AS/400 interface address to the same address as the NIC IP address. Also, do not add the NIC to the AS/400 TCP/IP interface list.

## Configuring With ADDTCPIFC

---

ADDTCPIFC is used to add a TCP/IP interface to the AS/400. This step configures the AS/400 for attachments to a TCP/IP network.

At the AS/400 command line, enter the following command:

```
ADDTCPIFC INTNETADR ('9.99.15.188') LIND(ETHLAN)  
SUBNETMASK ('255.255.255.0')
```

Your completed screen should look like Figure 23.

## Chapter 6 Configuring AS/400 For ASCII Using TCP/IP

---

System: BLDD6	
<b>Internet address:</b>	<b>9.99.15.188</b>
<b>Subnet mask:</b>	<b>255.255.255.0</b>
<b>Line description:</b>	<b>ETHLAN</b>
Line type:	*Elan
Interface status:	Inactive
Type of service:	*Normal
Maximum transmission unit:	*Lind
Automatic start:	*Yes

**Figure 23. Example of ADDTCPIFC Interface**

The following parameters must be specified:

### **Internet Address**

Internet address of the AS/400 LAN adapter.

**NOTE:** Do not use the IP address of the NIC.

### **Subnet Mask**

The Subnet Mask for this AS/400 TCP/IP interface (for example, 255.255.255.0).

### **Line Description**

The name assigned to the AS/400 line description as described in “Developing Line Descriptions With CRTLINETH” on page 81.

**NOTE:** Each AS/400 LAN adapter will have its own line description.

---

## Configuring A Router Definition With ADDTCP RTE

---

### Configuring A Router Definition With ADDTCP RTE

---

If necessary, use the ADDTCP RTE command to create a route definition. This is required if the printer is somewhere other than on a local segment and must cross bridges.

### Configuring A Local Domain And Hostname

---

The AS/400 print commands, described in “Setting Up Printing For ASCII Files” on page 86, require a local name and hostname. If you have already configured LAN attached TCP/IP printers on the AS/400 system, you will have a local domain name and hostname configured on the system.

**NOTE:** If you already have a local domain name and hostname configured on the system, do not change your setup.

If the local domain name and hostname file is empty, the file must be set up. This control file information is used to determine if a print request comes from an authorized host.

To configure the local domain and hostname, you will run the CFGTCP command and select Option “12” from the menu. Enter a local domain name, such as *city.company.com*. Enter a local hostname, such as *as400-01*. This is the name of your AS/400 system and must match the hostname for your system in the host entry table. Refer to “Configuring A TCP/IP Host Table Entry” for more information.

**NOTE:** If the printer and AS/400 are not on the same local LAN segment, use CFGTCP Option 2 to verify that there is a route defined in the TCP/IP route list.

### Configuring A TCP/IP Host Table Entry

---

Although creating a TCP/IP host table entry is optional, it is a good idea to take this step. Add the AS/400 name and the IP address of the LAN adapter to the “Host Table Entries.”

## Chapter 6 Configuring The AS/400 For Printing

---

### Configuring The AS/400 For Printing

---

To configure an AS/400 for printing, you must:

- set up the printing capability, and
- verify the setup with a print job.

You will need the following information:

#### Remote Printer Queue name

Set to 'd1prn' through 'd8prn'.

**NOTE:** The Remote Printer Queue name must be in lowercase letters. Do not use "PASS."

#### IP Address

The IP address for the NIC.

### Setting Up Printing For ASCII Files

---

The next step is to set up the remote printing capability. There are two ways to do this: you can either specify the LPR parameters manually each time you send a file to the printer, or use Remote Writer and a remote output queue for automatic printing to the printer.

#### To Use LPR Manually

1. Start TCP/IP, if it is not already running, by entering the command `STRTCP`.
2. At the AS/400 command line, enter `LPR`.
3. Figure 24 displays in **bold** the parameters you need to specify.

---

## Setting Up Printing For ASCII Files

Send TCP/IP Spooled File (LPR)

Type choices, press Enter.

<b>Remote system</b>	<b>RMTSYS</b>	<b>&gt;</b>	<b>*INTNETADR</b>
<b>Printer queue</b>	<b>PRTQ</b>	<b>&gt;</b>	<b>'d1prn'</b>
Job name	JOB		*
User			
Number			
Spooled file number	SPLNMBR		*ONLY
<b>Destination type</b>	<b>DETTYP</b>	<b>&gt;</b>	<b>*OTHER</b>
<b>Transform SCS to ASCII</b>	<b>TRANSFORM</b>	<b>&gt;</b>	<b>*YES</b>
<b>Manufacturer type and model</b>	<b>MFRTPMDL</b>	<b>&gt;</b>	<b>*WSCST</b>
<b>Internet address</b>	<b>INTNETADR</b>	<b>&gt;</b>	<b>'9.99.2.3'</b>

**Figure 24. ASCII LPR Parameters**

The following parameter values are required:

### **Remote System**

Enter the hostname of your printer or **\*INTNETADR**, which then prompts you to specify the IP address of your printer.

### **Printer Queue (PRTQ)**

Set to `'d1prn'` through `'d8prn'`. The remote printer queue name must be in lowercase letters, entered in single quotes.

### **Destination Type (DETTYP)**

Specify **\*OTHER** for the DETTYP parameter.

## Chapter 6 Configuring The AS/400 For Printing

---

### Transform (TRANSFORM)

Specify **\*YES**.

### Manufacturer Type and Model (MFRTYPMDL)

Select a manufacturer type and model. This is the name of the WSCO. Select **\*EPFX850** for Epson emulation.

**NOTE:** Select the Manufacturer Type Model based on the data type.

- a. Report printing, text only, no IGP or barcodes.

Manufacturer Type Model = **\*EPFX850**  
Workstation Customizing Object = **\*NONE**

Since EPFX850 is an Epson emulation, the printer emulation must be also switched to Epson emulation. Be sure to save the printer emulation as the power-up configuration.

- b. PGL or VGL or PPI program.

Manufacturer Type Model = **\*WSCST**  
Workstation Customizing Object = **QWPDEFAULT**  
Library = **QSYS**

This selects a generic object that passes the data unchanged without any escape codes to the printer. Text files will print in the currently selected printer configuration, cpi, lpi, and form length. OS/400 versions below V3R7 may not have this selection and may require manual creation of a generic WSCST. Please contact TallyGenicom Technical Support for assistance.

**NOTE:** For occasional text reports, create a printer configuration for each report and use the [Job Select] key to select a report configuration.

---

## Setting Up Printing For ASCII Files

### Internet Address (INTNETADR)

The IP address of the NIC.

**NOTE:** You may specify either **\*INTNETADR** (and the NIC IP address) or the hostname for the NIC (if you added the printer to the host table entry as directed in “Configuring A TCP/IP Host Table Entry” on page 85).

### To Create An Automatic Remote Output Queue

1. From the AS/400 command line, enter `CRTOUTQ`.
2. Figure 25 displays in **bold** the parameters you need to specify.

Send TCP/IP Spooled File (LPR)

Type choices, press Enter.

<b>Output queue</b>	<b>OUTQ</b>	<b>&gt;</b>	<b>USERNAME</b>
Library			*CURLIB
Maximum spooled file size:	MAXPAGES		
Number of pages			*NONE
Starting time			
Ending time			
	+ for more values		
Order of files on queue	SEQ		*FIFO
<b>Remote system</b>	<b>RMTSYS</b>	<b>&gt;</b>	<b>*INTNETADR</b>
<b>Remote printer queue</b>	<b>RMTprtQ</b>	<b>&gt;</b>	<b>'d1prn'</b>
<b>Writer to autostart</b>	<b>AUTOstrWTR</b>		<b>1</b>
Queue for writer messages	MSGQ		QSYSOPR
Library			*LIBL

## Chapter 6 Configuring The AS/400 For Printing

Connection type	CNNTYPE	> *IP
Destination type	DESTTYP	*OTHER
Host print transform	TRANSFORM	*YES
Manufacturer type and model	MFRTYPMDL	> (See Note on page 88)
Workstation Customizing Object	WSCST	> (See Note on page 88)
Library		
Internet address	INTNETADR	> '9.99.57.173'
Destination options	DESTOPT	*NONE
Print separator page	SEPPAGE	*YES
User defined option	USRDFNOPT	*NONE

**Figure 25. Automatic Remote Output Queue Configuration**

- Enter values for the following parameters:

### Output Queue (OUTQ)

The name of the AS/400 output queue. The name can be anything you would like. This name is not the same as the printer internal queue name, 'd1prn'.

### Remote System (RMTSYS)

Internet address of the NIC on the printer (\*INTNETADR prompts you for this) or the hostname of the NIC.

### Remote Printer Queue (RMPRTQ)

Default name of the network printer. Set for any of 'd1prn' through 'd8prn'. The remote printer queue name must be lowercase, entered in single quotes.

---

## Setting Up Printing For ASCII Files

### Writer to Autostart (AUTOSRTWTR)

Set the value to 1. This will start the Remote Writer when the queue is created, and it automatically starts the Remote Writer after each IPL of the AS/400 and whenever STRTCP is started.

### Connection Type (CNNTYPE)

Specify this value as \*IP.

### Destination Type (DESTTYP)

Specify \*OTHER. \*OTHER is a performance enhancement, in which data is not required to be transformed again if the connection is interrupted and allows printing of multiple copies.

### Transform (TRANSFORM)

Specify this value as \*YES.

### Manufacturer Type (MFRTYPMDL)

Select a manufacturer type and model. This is the name of the WSCO. Select \*EPFX850 for Epson emulation or \*IBM42023 for Proprinter Emulation.

## Troubleshooting

This installation procedure assumes that the NIC adapter is configured with the correct IP address, subnet mask, and gateway (if required). In addition you can also ping and telnet to the NIC adapter.

Print an E-net Test Page to verify the Ethernet settings. See "Printing A NIC Test Page" on page 22.

The default NIC queue name is d1prn, however, the name can be changed. Substitute the changed name for the RMTprtq parameter. To verify the queue name, print an E-Net Test Page or telnet to the NIC and perform a "list dest" command.

## Chapter 6 Verify Printing On AS/400

---

### Internet address (INTNETADR)

Specify the IP address of the printer.

## Verify Printing On AS/400

---

This section verifies that the printer is capable of printing ASCII files and that the printer can be pinged on the network.

To test ASCII printing:

1. Start TCP/IP, if it is not already running, by entering the command `STRTCP`.
2. Verify that the AS/400 TCP/IP interface is active.
3. Ping the printer from an AS/400 workstation with the command:  
`ping ip_address`.

Where *ip\_address* is the Internet address of the remote system printer (the NIC) or the hostname of the printer (if you put the hostname in the host entry table as directed in “Configuring A TCP/IP Host Table Entry” on page 85).

4. If the printer cannot be pinged, proceed to “AS/400 ASCII Troubleshooting” on page 93.
5. Use one of the following methods to send a spooled file to the printer:
  - Enter the LPR command on the AS/400 command line with the appropriate parameters. See “To Use LPR Manually” on page -86.
  - Enter `STRRMWTR name` on the AS/400 command line, where *name* is the name of the AS/400 remote output queue (not the printer Internet queue, as described on “To Create An Automatic Remote Output Queue” on page 89).
  - Use the `WRKOUTQ` command to send jobs.

---

## AS/400 ASCII Troubleshooting

---

During power up, the printer performs an interface hardware test. The presence of the ETHERNET PARAMS menu selection at the printer control panel indicates that the NIC hardware is functioning properly. See the *User's Manual* for configuration menu information.

If you have trouble pinging the printer:

1. Verify the configuration of the AS/400, including the printer and any intervening devices such as routers and bridges.
2. Verify that the AS/400 line description is varied on and the printer is turned on and displays an ONLINE status.
3. Verify that the AS/400 TCP/IP is active.

**Chapter 6** AS/400 ASCII Troubleshooting

---

---

# 7

## *Monitoring Printers*

---

### **Implementing Printer Management**

---

Printer management includes the following tasks:

- Monitoring the status of network printers
- Responding to alarms
- Gathering statistics on printer operations

The three elements of network printer monitoring and management are:

- Agent/manager model
- The management information database (MIB)
- SNMP, the protocol used to get management information

#### **Agent/Manager Model**

---

The elements of a monitoring system, MIB and SNMP, are implemented in an agent/manager model:

- The MANAGER is a console, workstation, or server on working hubs or routers which has a global knowledge of NICs and printers.
- AGENTS are utilities that reside on devices, such as a NIC, that respond through SNMP to management requests for information. The information is stored in an MIB.

## Chapter 7 Implementing Printer Management

---

### MIB

---

An MIB contains information a device makes available through SNMP. The MIB is a management information base that describes information about actual objects to be managed and controlled.

#### Standards Of Network Printer MIBs

The Printer MIB is based on the following standards:

- System and Interfaces Group MIB (RFC 1213 of March 1991)
- Host Resource MIB (RFC 1514 of September 1993)
- Printer MIB (RFC 1759 of March 1995)
- NIC contains the Standard Printer MIB per RFC 1759, available from [www.ietf.org](http://www.ietf.org).

#### Information Provided By The MIB

The printer MIB contains the following types of information about network printers:

**Descriptions.** Printer configuration, location, and contact.

**Status.** Current operating status of printers.

**Alerts.** Reportable events from printers.

#### General Information About MIBs

For further information on SNMP and MIB, refer to the following:

- RFC 1155 — Structure and Identification of Management Information for TCP/IP-based Internets (SMI)
- RFC 1156 — Management Information Base for Management of TCP/IP Internets (MIB)
- RFC 1157 — A Simple Network Management Protocol (SNMP)
- The Simple Book: An Introduction to Management of TCP/IP-based Internets

### **Getting The Latest MIB Information**

The latest copy of these and other RFCs can be obtained from the Internet Engineering Task Force (IETF) at <http://www.ietf.org>.

### **SNMP**

---

SNMP is the protocol used to communicate between manager and agent. Managers request information, usually through automated polling at specified intervals, and agents respond.

SNMP is a standard by which a network manager can get statistics and configuration information from the NICs and other devices on the network. This is done through a Network Management Station (NMS) such as NetView®. Currently only SNMP version 1 protocol is supported.

## **Monitoring Tools**

---

Many tools can be used to monitor printers with SNMP agents. One of these tools is NetView. There are also other MIB browsers which are not described here.

### **Monitoring With AIX NetView/6000**

---

The AIX NetView/6000 program can manage any IP-addressable device with an SNMP agent.

NetView/6000 can be used to set a network topology, monitor a network, diagnose problems, and measure network performance.

Through its MIB Browser, information about the resources affecting an event (such as an alarm) can be obtained.

## PrintNet Enterprise Suite

---

PrintNet Enterprise Suite (PNE) is a versatile remote management software utility. It allows you to organize all of the printers in your office remotely in a single database, download software and printer settings from a host computer with a single mouse click, and use a virtual operator's panel to configure printers in the same room or on the other side of the world. Refer to the *PrintNet Enterprise Suite User's Manual* or [www.Printronix.com](http://www.Printronix.com) for more details on this tool.

## Setting The SNMP Community Name

---

The default SNMP read-only community name is “public” and cannot be changed.

Change the SNMP R/W community name with the command:

```
set user passwd snmp com_name  
save
```

where *com\_name* is the new SNMP R/W community name.

The default is no R/W community name.

**NOTE:** Changing SNMP community names or access rights may hinder or disable applications that are monitoring your printers.

---

# 8

## *Commands*

---

### Command Shell Overview

The NIC comes with an in-depth command shell called `npsh`. It allows you to manipulate objects like destinations, I/O ports, and models and provides monitoring and troubleshooting capabilities.

---

#### **npsh Access Methods**

There are many ways this command shell can be accessed:

- built in HTML forms
- a Telnet session from a TCP/IP host to the NIC
- a single remote shell command (e.g., `rsh`, `rcmd`, `remsh`) from a TCP/IP host
- a `PTX_SETUP` command file containing one or more `npsh` commands sent through a printer data port (serial, parallel, etc.)

## Chapter 8 Command Shell Overview

---

### Main npsh Command Prefixes

---

All configurable commands either start with `store` or `set`, and view commands start with `list`.

**NOTE:** If the `store` prefix is used, the NIC must be repowered to make the changes take effect. Since `store` affects flash memory settings only, the print server must reset and read the new settings now in flash memory.

**NOTE:** If the `set` prefix is used, a `save` command must be executed as well so that the new settings are retained after power cycles. Since `set` only affects the settings in memory, they will be lost after a power cycle unless they are saved to flash memory.

### Getting Command Help

---

The NIC command shell provides several online help tools, including:

#### “?” Command

Typing “?” when logged in to the command shell will produce a full list of all available commands.

#### Command Prefixes

Typing in the first portion of a command will produce an error message showing the correct syntax. For example, typing in `store tcpip` will produce a list of all commands that start with this prefix.

---

## Complete Command List

---

This section outlines the entire NIC command set including the command syntax, a description, and in most cases, an example for each command listed.

**NOTE:** *ifnum* in any npsH commands is always 1.

### Store Commands

---

These commands change the settings stored in flash memory and do not affect the current or working settings in memory. A power cycle is needed before the stored settings become current.

```
store ifc ifnum utp [-]li [-]rx
```

Example: `store ifc 1 utp li`

Modify the physical UTP interface properties where `li` enables link integrity and `rx` enables the increased receive threshold.

```
store ifc from default
```

Set all UTP settings back to factory defaults.

```
store ifc from current
```

Store all current UTP settings to flash memory so they are retained after a power cycle. This ensures all current settings match what is stored in flash memory.

```
store ifc default <IFNUM>|<0> (0 for no default)
```

Store the specified interface as the default interface. The other interface is no longer active after power cycle. The 0 allows for both interfaces to be active.

```
store ifc <IFNUM> mode auto|10half|10full|100half|100full
```

Store the specified interface mode as automatic, 10mbps half duplex, 10mbps full duplex, 100mbps half duplex, 100mbps full duplex. See page 18.

## Chapter 8 Complete Command List

---

`store pping opts [-]enable`

Example: `store pping opts enable`

Store the state of periodic ping flag. If the periodic ping flag is enabled the NIC periodic ping client will attempt to ping its default gateway on its active NIC interfaces.

Default: disabled

`store pping packet <NUMBER OF PACKETS>`

Example: `store pping packet 1`

Store the value of the packet. It is the number of ICMP Echo Request packets that will be sent by the periodic ping client on each period.

Default: 1

`store pping period <MINUTES>`

Example: `store pping period 5`

Store the value of the period. <minutes> is the amount of time from 1 to 5 minutes defines the periodic ping sequence will be repeated.

Default: 5

`store pping from default`

Example: `store pping from default`

Store all the periodic ping default settings to flash memory so that they are retained after power up.

`store pserver name`

Example: `store pserver name NIC1234`

Command to change the print server name.

---

## Store Commands

```
store pserver opts [[-]jobsecurity]
[jobtimeout <SECONDS>] [jobcontrol[off|standard|
enhanced|fast]] [multcp[enable|disable|disablewithRST]]
```

**Example:** store pserver opts jobcontrol [off|standard|enhanced]

jobcontrol is used to have different levels of secure printing. This is available as a performance enhancement for LPR, TCP socket printing etc. When jobcontrol is set to enhanced all jobs will be supported with job flow control.

**NOTE:** When jobcontrol is disabled, dynamic config loading on a model change is also disabled.

- **off.** no job control; no SOJ/EOJ commands. The printer prints faster in off mode.
- **standard.** (the default) traditional job control with immediate acknowledgements of SOJ/EOJ commands.
- **enhanced.** job control with EOJ acknowledgements held off by the printer until job is fully printed. The printer prints slower in enhanced mode.
- **fast.** The EOJ (End of Job) packet is acknowledged immediately. This selection can be used if the Job was timed out due to a delay in the acknowledgement of the EOJ packet because of the amount of data being printed.

To monitor the printer, use the telnet command “lpstat.” The normal status reported on the first line of the lpstat response is the status of the queue (LPQ) within the NIC. The status reported does not reflect the state of the print job once it has been sent from the NIC to the printer.

The new line at the bottom of the lpstate response labeled “printer job:” can report one of two status values:

- a. **In Progress.** A job in the printer is not yet finished.
- b. **Done.** There are no jobs in the printer. All previous jobs are finished.

## Chapter 8 Complete Command List

---

Example: `store pserver opts jobsecurity jobtimeout 5`

If `jobsecurity` is disabled, any user can cancel queued jobs on the NIC including guest users. If `jobtimeout` is set to some value other than 0, the NIC will only wait this amount of *seconds* when getting printer feedback. This is only used if you have a `logpath` port and `type` set on a particular destination.

The `multtcp` option determines how many concurrent socket connections are allowed.

Example: `store pserver opts multtcp disable`

When `multtcp` is disabled, only a single socket connection is allowed at a time. The default is `multtcp` enabled.

Example: `store pserver opts multtcp disablewithRST`

With this option, only a single socket connection is allowed at a time. Other socket connection requests are refused with a RST packet.

Example: `store pserver opts multtcp enable`

With this option, multiple concurrent socket connections are allowed.

`store pserver tcpsocket <TCP-PORT> port <NEW-TCP-PORT>`

Example: `store pserver tcpsocket 4000 port 5000`

Change a pre-defined TCP port number (`<tcp-port>`) on the NIC to a new TCP port number (`<new-tcp-port>`). The default number is 9100 for `prn`.

`store pserver tcpsocket <TCP-PORT> dest <DEST>`

Example: `store pserver tcpsocket 5000 dest d1prn`

Assign a pre-defined TCP port number (`<tcp-port>`) to a particular destination (`<dest>`) on the NIC. Therefore, if you are using a print method that sends jobs directly to a TCP port number, you still have the option to process the job data through this destination setting.

`store pserver tcpsocket add <TCP-PORT> dest <DEST>`

Example: `store pserver tcpsocket add 9101 dest d2prn`

Maps the port number to a destination.

---

## Store Commands

store pserver tcpsocket del <TCP-PORT> dest <DEST>

Example: store pserver tcpsocket del 9101 dest d2prn

Deletes a mapped port number destination already defined by listed commands.

store pserver smb workgrp <WORKGROUP>

Example: store pserver smb workgrp eng

Define a different Windows workgroup as defined by <workgroup> for the NIC to be visible within (should be 14 characters or less). By default, the print server only comes up within the group called "WORKGROUP."

store pserver lpd [-]dest1default

Example: store pserver lpd dest1default

If dest1 default is disabled and upon verification, the printer name supplied by the LPR protocol and the destination name do not match, then an error message is returned and the service is refused. If dest1 default is enabled and upon verification, the printer name supplied by the LPR protocol and the destination name do not match, then the job is automatically routed to the first destination and the service is accepted.

Default: enabled

store pserver from default

Set all general print server settings back to factory defaults.

store pserver from current

Store all current general print server settings to flash memory so they are retained after a power cycle. This ensures all current settings match what is stored in flash memory.

store ptrmgmt pne <PNE PORT NUMBER>

Change the port number to communicate with Printnet Enterprise.

Default: 9001

## Chapter 8 Complete Command List

---

```
store ptrmgmt status <STATUS PORT NUMBER>
```

Example: `store ptrmgmt status 1025`

Receives printer status, print job status, and/or emulation verification data. The data sent through this port is defined by the printer code.

Default: 9002

```
store ptrmgmt mgmt <MGMT PORT NUMBER>
```

Used in PXML operation.

Default: 9007

```
store tcpip <IFNUM> addr <ADDRESS>
```

Example: `store tcpip 1 addr 192.75.11.9`

Store the IP address for the NIC.

```
store tcpip <IFNUM> mask <MASK>
```

Example: `store tcpip 1 mask 255.255.255.0`

Store the subnet mask for the NIC.

```
store tcpip <IFNUM> opts [[-]rarp] [[-]bootp] [[-]dhcp]
[[-]persistdhcp] [[-]dns]
```

Example: `store tcpip 1 opts -rarp -bootp -dhcp`

Enable or disable the automatic RARP, BOOTP, DHCP, DNS, or persistent DHCP requests for IP addresses upon bootup. If you are storing the NIC TCP/IP network settings within the device, you will not need to rely on RARP, BOOTP, DHCP, or DNS for new settings.

```
store tcpip IFNUM frametype [[-]ethernet2]
[[-]802.2snap]
```

Example: `store tcpip 1 frametype ethernet2 802.2snap`

Control which frame type(s) is supported with the TCP/IP protocol. By default, both `Ethernet 2` and `802.2snap` are enabled, but normal TCP/IP communications rely on Ethernet 2.

---

## Store Commands

```
store tcpip route add default [1|2] <ROUTER> <IFNUM>
[<METRIC>]
```

**Example:** `store tcpip route add default1 192.75.11.1 1`

Store a default router/gateway defined by router IP Address (<router> <ifnum>) so the NIC knows where to direct packets destined for another subnet. It is easier to store one default entry rather than an entry per remote host or network as in the previous command.

```
store tcpip del default [1|2]
```

**Example:** `store tcpip route del default1 192.75.11.1 1`

Delete a default router/gateway defined by router IP Address (<router> <ifnum>) so the NIC knows where to direct packets destined for another subnet.

```
store tcpip route add [host|net] <NETWORK> [/mask>]
<ROUTER> <IFNUM> [<METRIC>]
```

**Example:** `store tcpip route add net 192.75.12.0 1`

Add a static route to a particular TCP/IP host or subnet specified by <network> so the NIC knows how to communicate with it. Normally one entry for a default router/gateway is all that is needed for communications between different subnets. Please see the next command for details.

```
store tcpip route del [host|net] <NETWORK>
```

**Example:** `store tcpip route add net 192.75.12.0 1`

Delete a static route to a particular TCP/IP host or subnet specified by <network> so the NIC knows how to communicate with it. Normally one entry for a default router/gateway is all that is needed for communications between different subnets. Please see the next command for details.

```
store tcpip tcp rxwin <PACKETS>
```

**Example:** `store tcpip tcp rxwin 2`

Determine the receive window size for the NIC. The *packets* value ranges from 2 to 8, which is the number of MSS. If the *packets* value is greater than 256, the value represents the number of bytes.

## Chapter 8 Complete Command List

---

```
store tcpip tcp opts [-]keepalive [-]zeroIPArp
[-]keepalivedata
```

Example: `store tcpip tcp opts keepalive`

Control whether the NIC maintains a connection with a host when data cannot be accepted into its buffer. Normally the `keepalive` feature is enabled so when the printer cannot accept data, the print job connection is maintained and continued once the situation clears. The `keepalivedata` option controls whether the keepalive packet contains a data byte for hosts that require it. If `zeroIPArp` is disabled then a NIC with an IP address of 0.0.0.0 will not allow IP access until the IP address is configured. If `zeroIPArp` is enabled on a NIC with an IP address of 0.0.0.0 then any attempted access with a valid IP address is assumed for this NIC and an Arp lookup is performed.

Default: enabled

```
store tcpip tcp access [root] add|del <NETWORK>
[<NETMASK>]
```

Example: `store tcpip tcp access add 192.75.11.25`

Add or remove an entry from the NIC TCP access list defined by `<network>`. If the list has an entry, only this host can print to and remotely interact with the print server.

```
store tcpip from default|current
```

Example: `store tcpip from default`

Set all TCP/IP network settings back to factory defaults.

Example: `store tcpip from current`

Store all current TCP/IP network settings to flash memory so they are retained after a power cycle. This ensures all current settings match what is stored in flash memory.

## Set Commands

---

These settings alter the current or working settings in memory only. Therefore, they will be lost if the NIC is power cycled. To ensure this does not happen, issue a `save` command so the current settings get written to flash memory.

```
set dest <DEST> name <NEW_NAME>
```

Example: `set dest d1prn name line matrix`

Change the current name of the `<dest>` to a new name as indicated by `<new_name>`. These names are case sensitive.

```
set dest <DEST> backchannel [prn]
```

Example: `set dest d1prn backchannel prn`

Establish a return path for printer feedback for a given destination (`<dest>`). The NIC I/O port is bi-directional, however, you will most likely use the same I/O port to which the destination is currently sending jobs.

```
set dest <DEST> alternate [<ALT_DEST>]
```

Example: `set dest d1prn alternate d4prn`

Sets an alternate destination for a queue other than itself.

```
set dest <DEST> model <MODEL>
```

Example: `set dest d1prn model m4`

Associate a model with a destination. Jobs sent to the named destination (`<dest>`) are processed according to the options defined in the named model.

```
set dest <DEST> logpath <LOGPATH>
```

Example: `set dest d1prn logpath 14`

Associate a logpath with a destination. Jobs sent to the named destination (`<dest>`) are logged according to the settings defined in the named logpath.

## Chapter 8 Complete Command List

```
set dest <DEST> service [[-]socket] [[-]lpd]
[[-]lpsched] [[-]netbios] [[-]ftpd]
```

Example: set dest dlprn service -netbios

Set the destination (<dest>) to handle only certain print services. To add a service, specify the service name. To disable a service, use “-” before the name. The available services are described in the following table.

Services	
socket	Direct socket printing via TCP/IP.
lpd	LPR printing with TCP/IP, including LPR clients on any platform.
lpsched	LP or System V printing with TCP/IP.
netbios	Windows 95 and Windows for Workgroups printing.
ftpd	Printing using the File Transfer Protocol (FTP) via TCP/IP.

```
set dest from default
```

Set all destination settings back to factory defaults.

```
set dest from stored
```

Set all current destination settings to the values stored in flash memory.

```
set ifc <IFNUM> up|down
```

Example: set ifc 1 up

Set state of the specified network physical interface up or down. <ifnum> is the interface number for the NIC device.

```
set logpath <LOGPATH> name <NEW_NAME>
```

Example: set logpath l1 name pagecount

Change the current name of the logpath (<logpath>) to a new name as indicated by <new\_name>. These names are case sensitive.

---

## Set Commands

```
set logpath <LOGPATH> type [[-]job] [[-]user]
[[-]cksum] [[-]printer] [[-]ioport]
```

**Example:** `set logpath l2 type job user printer pgcnt`

Establish the type of printer and print job logging to be done within this <logpath>. The options are:

<b>job</b>	Job ID, username, etc.
<b>user</b>	User ID along with three messages per job about start and finish.
<b>cksum</b>	16-bit checksum value to confirm integrity of data printed.
<b>printer</b>	For special printer feedback.
<b>ioport</b>	Printer error messages determined through the parallel port pins.

```
set logpath <LOGPATH> port <TCP-port>|email|syslog
```

**Example:** `set logpath l3 port 2000`

Determine where the log information should be sent for a print job or attached printer. The choices are:

<b>TCP-port</b>	TCP port number ranging from 1024 to 65000.
<b>email</b>	Particular user's email address. This address is set using the <code>set sysinfo email emailname@IPaddress</code> or <code>emailname@domain.com</code> command.
<b>syslog</b>	A central TCP/IP host running the SYSLOG daemon. This host is set using the <code>set sysinfo syslog IPaddress</code> command.

```
set logpath from default
```

Set all logpath settings back to factory defaults.

```
set logpath from stored
```

Set all current logpath settings to the values stored in flash memory.

## Chapter 8 Complete Command List

---

```
set lpd [-]bytecount
```

**Example:** `set lpd -bytecount`

Set the job control on the file size of a Line Printer Daemon (LPD). If `bytecount` is enabled, the printer does not allow the LPD client to send a job with an unconventional file size. Usually the unrecognized numeric operand in the LPD Receive Data File command attributes to this behavior. The print job stream is canceled and its TCP connection is closed.

**Default:** Disabled.

```
set lpd [-]offlinedata
```

The `offlinedata` flag helps minimize host disconnects when the printer goes offline for an extended time. Enable this option if you experience host disconnects when the printer goes offline.

```
set model <MODEL> name <NEW_NAME>
```

**Example:** `set model m1 name landscape`

Change the current name of the model (`<model>`) to a new name as indicated by `<new_name>`. These names are case sensitive.

```
set model <MODEL> type raw
```

**Example:** `set model m2 type raw`

Set the model `type` to `raw` so that it does not process the data passing through it in any way.

```
set model <MODEL> banner [text] [after]
```

**Example:** `set model m2 banner text`

Determine whether a banner page should be added for print jobs passing through the `<model>` mapped destination/queue. By default, banner pages are added to the front of the job. If `after` is set, the banner page will come at the end.

---

## Set Commands

```
set model <MODEL> stty [[-]onlcr] [[-]descramble]
[xtab <1-16>|none]
```

**Example:** `set model m3 stty onlcr`

Control extra job processing done by the <model>. The processing options are:

- |                   |  |
|-------------------|--|
| <b>onlcr</b>      | Carriage return insertion for Unix text jobs. Adds carriage returns to text jobs with solitary linefeeds. This will prevent stair-stepped output or output running off the right side of the page. |
| <b>descramble</b> | Automatic descrambling of print jobs passing through which have been scrambled using TallyGenicom proprietary Unix scramble utility, <code>npstramble</code> .                                     |
| <b>xtab</b>       | Tab expansion from 1 to 16 spaces.   |

```
set model <MODEL> header [<STRING>]
```

**Example:** `set model m1 header 0x20`

Set a header string to be sent to the printer at the start of any print jobs passing through this <model>. The headerstring (<string>) can consist of up to nine elements. An example element is a hexadecimal code (e.g., 0x04) or a pre-defined variable on the print server (e.g., \$FF for a formfeed). Use *list var* to see all available variables. To erase the header, send the command with no *headerstring* value; for example 'set model m1 header'.

```
set model <MODEL> trailer [<STRING>]
```

**Example:** `set model m7 trailer $FF`

Set a trailer string to be sent to the printer at the end of any print jobs passing through this <model>. The trailerstring (<string>) can consist of up to nine elements. An example element is a hexadecimal code (e.g., 0x04) or a pre-defined variable on the print server (e.g., \$FF for a formfeed). Use *list var* to see all available variables. To erase the trailer, send the command with no *trailerstring* value; for example 'set model m1 trailer'.

## Chapter 8 Complete Command List

---

```
set model <MODEL> config [config_num]
```

Set a printer configuration number config\_num to be loaded prior to printing a job on the specified model. If the command is sent with config\_num set to 0, the factory configuration is loaded before the job prints. If config\_num is in the range 1 through 8, the corresponding configuration number is loaded before the job prints. To return to the default state where no configuration is loaded, send the command with no config\_num value; for example 'set model m1 config'. When no new configuration is loaded, the current configuration settings will be in effect for any jobs sent to model <model>. To see which configuration, if any, will be loaded at the start of a job, use the command 'list model' or 'list model <model>'.

```
set model from default
```

Set all model settings back to factory defaults.

```
set model from stored
```

Set all current model settings to the values stored in flash memory.

```
set prn [-]autofd
```

Example: set prn -autofd

Assert or do not assert the AUTOFD line for carriage return insertion. This only affects printers that support this function, such as impact printers.

```
set prn flush
```

Flush the data in the parallel port input and output buffers.

```
set prn unlock
```

Release the access lock on the parallel port.

```
set prn timeout <INT>|none
```

Example: set prn timeout none

Terminate the print job sent to the parallel port if it is not printed after the timeout period in minutes (<int>) expires. The <int> value ranges from 0 though 255, with 0 indicating no timing out to take place. This is the default setting and should be fine for most print setups.

---

## Set Commands

set prn [-]opost

Example: set prn -opost

Allow or disallow output processing on the parallel port such as carriage return insertion (e.g., onlcr).

set prn [-]onlcr

Example: set prn -onlcr

Enable or disable carriage return insertion on the parallel port. This may be needed for Unix text jobs coming through with solitary linefeeds. This feature is almost always set at the model level rather than the I/O port level.

set prn xtab <INT>|none

Example: set prn xtab none

Set the tabstop width as indicated by <int>. The range is 1 through 16 spaces.

set prn from default

Set all parallel port settings back to factory defaults.

set prn from stored

Set all current parallel port settings to the values stored in flash memory.

set snmp

To add a user named `snmp` with root privileges, follow the steps below:

1. Login to the Ethernet as a root user.
2. Add a user named `snmp`:  
set user add snmp
3. Set the user type to `root`:  
set user type snmp root
4. Set the password for the `snmp` user:  
set user passwd snmp *snmppassword*
5. Save the changes:  
save

The user `snmp` is now created and *snmppassword* is the only community string which will allow write access.

## Chapter 8 Complete Command List

---

```
set snmp manager <INDEX> <IPADDRESS> <TRAP-COMMUNITY>
```

The NIC continuously generates traps. To set the NIC to send traps to a particular SNMP manager, use this command to add an SNMP manager to the trap table.

<index> is the index number of the trap table. <ipaddress> is the IP address of the SNMP manager receiving traps. <trap-community> is the community string sent along with the trap information.

```
set snmp trapport <INDEX> <UDP_PORT>
```

Set the UDP port number in the SNMP trap manager table. This value should correspond to the port number monitored by the SNMP manager application running on the host at the IP address specified in the 'set snmp manager' command.

<index> is the index number of the SNMP trap manager table. <udp\_port> is the desired UDP port number. Acceptable values are 162, and 49152 through 65535.

```
set snmp trap <INDEX> [-]active
```

Enable or disable an SNMP trap manager table entry.

The *index* is the index number of the SNMP trap manager table. "active" enables the table entry, "-active" disables the entry.

```
set snmp emailaddr <INDEX> <EMAILADDRESS>
```

The NIC can also send SNMP alert messages to a desired e-mail address. To specify an e-mail address to send alert messages to, use this command to add the e-mail address to the SNMP alert table.

<index> is the index number of the SNMP trap manager table. The *emailaddress* is the desired e-mail address of the form *user@domain.com*.

---

## Set Commands

```
set snmp emailformat <INDEX> [-]short
```

Enable or disable the short e-mail message format for an SNMP alert table entry. When enabled, the short e-mail format can be used when messages will be viewed on devices having a limited display size (a cellular phone or pager, for example).

<index> is the index number of the SNMP alert table. “short” enables the short e-mail format, “-short” disables it.

```
set snmp shortmsglen <INDEX> <LENGTH>
```

Specify the length of the short e-mail message format for an SNMP alert table entry. This command is effective only when the short e-mail message format for an SNMP alert table entry is enabled.

<index> is the index number of the SNMP alert table. “length” specifies the length of the short e-mail message, and has an acceptable range of 15 to 80 characters.

```
set snmp email <INDEX> [-]active
```

Enable or disable sending e-mail alert messages for an SNMP alert table entry.

<index> is the index number of the SNMP alert table. “active” enables sending e-mail alert messages, “-active” disables it.

```
set snmp alerts <index> [-]all | [[-]warning]
[[-]offline] [[-]mediainput] [[-]mediaoutput]
[[-]mediapath] [[-]marker] [[-]cutter] [[-]barcode]
[[-]scanner] [[-]intervention] [[-]consumable]
[[-]label] [[-]powercart] [[-]rfid]
```

Example: `set snmp alerts 1 warning -cutter]`

Specifies which alert groups are enabled for reporting via an SNMP manager, e-mail alert message, and/or Unix syslog daemon. See Table 1 on page 49 for a description of specific printer events belonging to each group.

The *index* is the index number of the SNMP manager/alert table.

## Chapter 8 Complete Command List

---

“-all” disables and “all” enables reporting of alerts in all alert groups. Individual alert groups can be selectively enabled or disabled via combinations of alert group switches. For example, to enable warning alerts and disable cutter alerts for SNMP table entry 1, enter the following:

```
set snmp alerts 1 warning -cutter
```

```
set snmp syslog <INDEX> [-]active
```

The NIC can also log SNMP alert messages to the defined SYSLOG host (see the ‘set sysinfo syslog’ command description). Use this command to enable or disable logging of alert messages for an SNMP alert table entry.

<index> is the index number of the SNMP alert table. “active” enables alert message logging, “-active” disables it.

```
set sysinfo label|name [<STRING>]
```

```
Example: set sysinfo name salesprinter
```

Set a descriptive name defined by <string> for NIC identification purposes. This is not used in the operation of the print server in any way.

```
set sysinfo contact [<STRING>]
```

```
Example: set sysinfo contact Paul_Harris
```

Set a person or department to contact in case of print server trouble.

```
set sysinfo location [<STRING>]
```

```
Example: set sysinfo location salesdept
```

Set the physical location of the NIC. This is for identification purposes and is not used in the operation of the print server in any way.

```
set sysinfo prnserial [<STRING>]
```

```
Example: set sysinfo prnserial 000123456789
```

Sets the printer serial number.

---

## Set Commands

```
set sysinfo loginfo [-]sys | [-]tcp
```

```
Example: set sysinfo loginfo -sys
```

Set the NIC debugging information type. Usually this information includes unexpected errors or exceptions from the print server divided into these groups:

**sys**            General system messages

**tcp**            TCP stack messages

**NOTE:** This is not printer or job logging information.

```
set sysinfo logport null|prn|syslog
```

```
Example: set sysinfo logport null
```

Define to where the debugging information should be sent. This can be sent to an output device off of the NIC I/O port or to a central TCP/IP host running a SYSLOG daemon. To set this host, use the command `set sysinfo syslog hostIPaddress`.

```
set sysinfo smtp <IPaddress> [port <PORTNUM>]
```

```
Example: set sysinfo smtp 192.75.11.5 port 25
```

Define the SMTP (Simple Mail Transfer Protocol) server IP address or domain name and port number where the mail is stored on your network.

Default: Unconfigured, 25

```
set sysinfo email <EMAIL>
```

```
Example: set sysinfo email JohnDoe@TallyGenicom.com
```

Define the user email address to receive printer and job logging information from a particular logpath on the NIC. Email name is the host or IP name of the user.

Default: Unconfigured

```
set sysinfo email emailname@domain
```

```
Example: set sysinfo email joe@tallygenicom.com
```

Define the user email address to receive printer and job logging information from a particular logpath on the NIC.

## Chapter 8 Complete Command List

---

```
set sysinfo syslog hostIPaddress
```

```
Example: set sysinfo syslog 192.75.11.30
```

Set the IP address of the host running the SYSLOG daemon. NIC debugging or print job and printer logging information can be sent to that IP address.

```
set sysinfo dns <IPaddress>
```

```
Example: set sysinfo dns 192.75.11.2
```

Set your DNS server IP address so the NIC can resolve host names when used with its built-in Telnet and ping clients.

```
set sysinfo domain <NAME>
```

```
Example: set sysinfo domain tallygenicom.com
```

Sets the domain name for the NIC, which when combined with the print server name, forms the fully qualified domain name of the NIC.

```
set sysinfo module [[-]novell] [[-]netbios]
```

```
Example: set sysinfo module -novell
```

Enable and disable certain network protocol stacks within the NIC. Sometimes it helps to disable any protocols you are not using on your network.

**NOTE:** [ - ] novell option is not available on the Integrated NIC.

```
set user add|del <NAME>
```

```
Example: set user add eng
```

Add or remove a user on the NIC defined by <name>.

### IMPORTANT

**Do not delete the root user, or you will be unable to configure any further settings on the print server. You will have to go back to factory defaults to correct this problem.**

```
set user passwd <NAME> [<PASSWORD>]
```

```
Example: set user passwd eng mplex1
```

Assign a password to a defined user on the NIC.

```
set user type <NAME> root|guest
```

```
Example: set user type eng root
```

Assign root or guest privileges to a particular user defined by *username*. Guest permissions allow viewing of settings only. Root permissions allow complete control of the NIC.

---

## Set Commands

```
set user from default
```

Set all user settings back to factory defaults.

```
set user from stored
```

Set all current user settings to the values stored in flash memory.

```
set user passwd snmp <COM_NAME>
```

Set the new SNMP R/W community name as the <com\_name> value.

```
set var <VAR> [<VARIABLE-STRING>]
```

**Example:** `set var LANDSCAPE 0x1b 0x26 0x6c 0x31 0x4f`

Define a new variable to be used in header, trailer, or switch strings on the NIC and call it <variable-string>. <variable-string> can be a space-separated list of words, hexadecimal numbers (e.g., 0x04), or references to other pre-defined variables. It is easiest to make up the <variable-string> with hexadecimal values, as shown in the example.

**NOTE:** One variable counts as one element within header and trailer strings.

Defined variables are referenced in strings by placing a “\$” before the variable name (e.g., `set model m1 trailer $FF`).

```
set var from default
```

Set all variable settings back to factory defaults.

```
set var from stored
```

Set all current variable settings to the values stored in flash memory.

## Chapter 8 Complete Command List

---

### List Commands

---

These commands list the current or working settings for a particular section within the command shell. To view stored settings in flash memory, insert `stored` after `list`. For example, `list prn` shows the current printer settings but `list stored prn` shows the settings in flash memory. Normally these should match. To view default settings in flash memory, insert `default` after `list`.

`list all`

Lists all current settings.

`list arp`

List the current ARP table that the NIC adheres to in a TCP/IP network.

`list dest [destination]`

List the current destination settings (e.g., names and mapped I/O ports, models, and logpaths).

`list diff`

List the differences between the current settings and the stored settings in flash memory. Normally, you want these values to match, so issue a `save` command followed by a `reset` command.

`list ifc`

Lists the current NIC interface settings (e.g., link integrity).

`list key`

List the license details and license key number.

`list logins`

List any active user logins on the NIC.

`list logpath [logpath]`

List the current logpath settings (e.g., names and mapped destinations).

---

## List Commands

`list model [model]`

List the current model settings (e.g., names and mapped destinations). With no *model* parameter, a table of values for name, type, banner, config and the size in bytes of header and trailer are shown for all models m1 through m8. When the *model* parameter is supplied, the specific bytes used in the header and trailer are shown, along with the banner type, data type and configuration number for that specific model.

`list net`

List all current TCP/IP network settings (e.g., IP address and subnet mask).

`list pping`

List all the current periodic ping setting.

`list pserver`

List the current general print server settings.

`list prn`

List the current parallel port setting (e.g., mode).

`list ptrcfg`

List the printer configuration

`list ptrmgmt`

List the current printer management port numbers.

`list snmp`

List the Trap Table containing SNMP Managers.

`list sysinfo`

List the current NIC system information (e.g., contact name and protocol stacks enabled).

`list tcpip`

List all current TCP/IP network settings (e.g., IP address and subnet mask).

`list test`

List the status of output tests on the I/O ports.

`list uptime`

Lists how long the NIC has been up and running from the last reset.

## Chapter 8 Complete Command List

---

`list user`

List the current user definitions (e.g., user names and types).

`list var`

List all pre-defined variables including any newly created ones. Any of these defined variables can be referenced in a string by placing a “\$” before the variable name (e.g., `set model m1 trailer $FF`).

`list dhcp`

List all DHCP information for the NIC provided that DHCP is enabled.

`list lpd`

List the Line Printer Daemon (LPD) information, such as whether the bytecount is enabled or disabled.

### Miscellaneous Commands

---

These commands do not fall under any specific section of the command shell, but they are used quite frequently.

`save [default]`

Save the current settings to flash memory so they are available after power cycles. `Sysinfo`, `destination`, `model`, `logpath`, `variable`, `user`, and I/O port settings will be saved. If `default` is specified as well, factory settings will be saved, overwriting any new settings you have configured.

`reboot`

Perform a warm boot or hardware reset to simulate a power-on reset. This restores current settings to those stored in flash memory, since the flash memory settings will be read and loaded into memory upon bootup.

`reset`

Perform a warm boot or hardware reset to simulate a power-on reset. This restores current settings to those stored in flash memory, since the flash memory settings will be read and loaded into memory upon bootup.

---

## Miscellaneous Commands

`load [default]`

Load the settings stored in flash memory and use them as the current or working settings. If `default` is specified as well, factory settings will be loaded.

`lpstat [ioport] [jobID]`

Example: `lpstat prn`

Display active and queued jobs and I/O port status for a given *ioport* or *jobID*. Specifying one of these parameters will shorten the output and focus on the particular I/O port or print job specified.

`cancel jobID`

Example: `cancel d1prn-10`

Remove a job from an I/O port queue. Use `lpstat` to find a particular job ID first.

`start fox|tts|loopb prn`

Example: `start fox prn`

Begin a debugging test on one of the I/O ports on the NIC. The tests available are:

- |              |  |
|--------------|--|
| <b>fox</b>   | A continuous stream of text sent to the attached printer. This is a good test for troubleshooting hardware as long as the attached printer supports text output. |
| <b>tts</b>   | A continuous stream of Gandalf 400C TTS-compatible text sent to the attached printer.  |
| <b>loopb</b> | Loopback test. Any input characters from the device attached to the I/O port is echoed back.   |

`stop all|prn`

Stop an output test on an I/O port.

## Chapter 8 Complete Command List

---

`disable ioport|destination/tftp`

Example: `disable prn`

Disable an *I/O port* so that queued jobs are not printed, or disable a *destination* so jobs cannot be queued to it. Use *lpstat* to see the current I/O state. Use *list dest* to see the *destination* state.

Example: `disable tftp`

Disables processing of a boot file located on a TFTP server.

`enable ioport|destination/printermgr/tftp`

Example: `enable prn`

Enable an *I/O port* so that queued jobs are printed, or enable a *destination* so jobs can be queued to it.

Example: `enable printermgr`

Enables the printer debug port to allow remote printer management software to function.

Example: `enable tftp`

Enables processing of a boot file located on a TFTP server.

`close tcp TCPindexnumber`

Example: `close tcp 3`

Close the a TCP/IP connection between a TCP/IP host and the NIC. The *TCPindexnumber* can be retrieved from “debug tcp” output.

`ping [-s] hostIPAddress [datasize [packetnumber]]`

Example: `ping 192.75.11.30`

ping another TCP/IP host specified by *hostIPAddress* on the NIC network. *datasize* is the datagram packet size which defaults to 64 bytes if no size is included in the syntax and *packetnumber* is the number of requests to be sent.

**NOTE:** To use a host or IP name instead of the address, you must have set the DNS server on the NIC. Use the command `set sysinfo dns...` to do this.

---

## Miscellaneous Commands

`telnet hostIPAddress [escapecharacter]`

Example: `telnet 192.75.11.35`

Start a Telnet session with another TCP/IP host specified by *hostIPAddress* on the NIC network. If *escapecharacter* is used, it resets the key sequence used to exit the Telnet session. It will return you to the `telnet>` prompt where you can execute *quit*. Use the *keycode* command to find out exact escape characters if needed. The default character is CTRL ].

**NOTE:** To use a host or IP name instead of the address, you must have set the DNS server on the NIC. Use the command `set sysinfo dns...` to do this.

`chr <STRING>`

Echo `<string>` or redirect `<string>` to an I/O port using the `chr <string> ioport`.

`keycode`

Determine the hexadecimal value for a key to be used as the escape character with the NIC built-in `telnet` command.

? (Help)

Lists all available commands.

**Chapter 8** Complete Command List

---

---

# 9

## *Extra Features*

---

### NIC Security

---

There are TCP access lists available to restrict host connections with the device.

#### Users And Passwords

---

The NIC supports two user types:

<code>root</code>	Access to everything within the print server including all configurable settings.
<code>guest</code>	Ability to list settings only.

Passwords can be set for each user type. However, most often you will just set a password for the `root` user to protect the NIC configuration. `Guest` users cannot alter the print server configuration in any way.

To configure a `root` password on your NIC:

1. Load a Web browser on a network station that can communicate with the print server over TCP/IP. The commands to set a `root` password are:

Syntax:

```
set user passwd username password
save
```

Example:

```
set user passwd root your_password_for_root
save
```

## Chapter 9 NIC Security

---

2. Direct your Web browser to URL:

`http://NICIPaddress/adminConf.html`

(e.g., `http://192.75.11.9/adminConf.html`).

**NOTE:** If prompted for a “User ID” and password first, type in `root` for the user ID and press ENTER at the password prompt (since there is no password by default).

3. At the “Administration Configuration” HTML form that displays, scroll down to the “Passwords” section.
4. Click within the “Old” field beside the “Root Password” heading and enter the existing root password. By default, there is no root password, so you can go to the next step without typing anything in this field.
5. Within the “Root Password” section, click within the “New” field and enter the new root password.
6. Within the “Root Password” section, click within the “Confirm” field and enter the new root password again. Remember this is case sensitive.
7. Click on the SUBMIT button when done and physically repower the print server to make the new setting take effect.

From this point on, anytime you log in to the NIC as `root`, you will need to specify this password or your login attempt will fail.

**NOTE:** To clear this password or change it, use the same “Administration Configuration” HTML form. Just enter the appropriate “Old” password and put in the new one (or nothing if you do not want a root password any longer). The commands directly on the NIC are:

```
set user from default
save
```

---

## Reset The NIC Password

---

### Reset The NIC Password

---

Occasionally a user will set a root user password on the NIC adapter and then forget it. This is the procedure to reset the root password back to the default (no password).

1. Turn the printer on.
2. Take the printer offline and unlock the front panel by pressing the up and down arrows keys at the same time, then releasing.
3. Press all four arrow keys (up, down, prev, next) at the same time, and release. "PRINTER MGMT" displays.
4. Press the down arrow. "Debug Port Cfg" displays.
5. Press the down arrow and then the right (next) arrow until "E-NET To DEFAULT" displays.
6. Press Enter.
7. Re-program the IP address information from the front panel.

**NOTE:** Steps 1 – 5 also clears the IP address information and sets the NIC back to the factory default.

### TCP Access Lists

---

Within TCP/IP environments, the NIC can restrict host access to destinations/queues and remote command (e.g., rsh, rcmd, remsh, and telnet) execution services. This is done using an access list similar in function to the Unix .rhosts file.

**NOTE:** Access list settings are not configurable through the HTML forms provided with the NIC.

To view the current access list on the print server:

1. Start a Telnet session with the NIC.

Syntax:

```
telnet NICIPaddress
```

2. Log in as `root` and press ENTER at the password prompt since there is no password by default (or your password for your home set).

## Chapter 9 NIC Security

---

3. List the current access list.

Syntax:

```
list tcpip
```

If the list is empty, all hosts have access to the NIC services. If there are entries in the list, only those hosts specified have access to printing and remote command execution.

To add and delete access list entries, the commands are:

Syntax:

```
store tcpip tcp access add|del hostIPAddress|  
networkaddress  
reset
```

where *hostIPAddress* is the IP address of a TCP/IP host on your network and *networkaddress* is the address of a subnet on your network.

Example:

```
store tcpip tcp access add 192.75.11.25  
store tcpip tcp access add 192.75.12.0  
store tcpip tcp access del 192.75.11.25  
reset
```

**NOTE:** Although the maximum number of entries in the access list is 10, each entry can refer to a network rather than a specific host. This allows all hosts on that specified network and any individual hosts specified in the list to have access.

## Printer Monitoring And Logging

---

The NIC allows you to monitor printer status and log information through its built-in HTML forms, command set, and logpaths.

### Printer And Print Job Monitoring

---

To view the current status of an I/O port on the NIC, two methods are available:

- select the desired I/O port on the “Status” HTML form (i.e., `http://NICIPaddress/indexStatus.html`; e.g., `http://192.75.11.9/indexStatus.html`) that comes with the NIC.
- enter the `lpstat` command directly on the print server once logged in as `guest` or `root`.

In each case, you are given a description of each I/O port status and a list of queued jobs. Table 3 describes some of the common terms you may encounter.

**Table 3. Key Printer Logging Terms**

Term	Description
idle	There is no job queued for the NIC I/O port.
blocked	The printer is not allowing the NIC to send data to it. Check that there is not a printer error and it is online and ready to go.
waiting	The NIC knows about a print job but is waiting for the host to send more data or to send an expected packet.

## Chapter 9 Printer Monitoring And Logging

---

### Printer Logging Through Logpaths

---

In the NIC product manual, destinations are described as logical queues with associated models and logpaths. Models determine if any extra processing is needed with the print jobs passing through, and logpaths determine whether any logging is needed for each job.

Each logpath on the NIC consists of two parts:

TYPE	The type of log information to be captured. The choices are <code>job</code> for job ID and username, <code>user</code> for user ID (and three messages per job), <code>cksum</code> for file checksums, <code>printer</code> for special printer feedback, and <code>ioport</code> for parallel printer status messages.
PORT	Where this log information will be sent to. The choices are a TCP port number (e.g., 2000), an email address (including an alias), or a central host running a SYSLOG daemon.

To view the current logpath settings on the print server:

1. Load a Web browser on a network station that can communicate with the print server over TCP/IP or using Telnet (e.g. Telnet *ipaddress*). The command to view the logpath settings is:

Syntax:

```
list logpath
```

**NOTE:** If prompted for a “User ID” and password first, type in `root` for the ID and press ENTER at the password prompt since there is no password by default.

2. Direct your Web browser to URL  
`http://NICIPaddress/destConf.html`  
(e.g., `http://192.75.11.9/destConf.html`).

**NOTE:** If prompted for a “User ID” and password first, type in `root` for the ID and press ENTER at the password prompt (since there is no password by default).

---

## Printer Logging Through Logpaths

---

3. At the “Print Path Configuration” HTML form that displays, select a destination link (e.g., d1prn) from the top of the page to bring up the appropriate destination form.
4. Once the desired destination HTML form displays, scroll down to the “Logpath Type” and “Logpath Port” sections to view the current logpath settings for this particular destination.

At this point, you can alter any of these settings and then click on the SUBMIT button to store them into the NIC. Remember to repower the NIC to make the settings take effect.

## Downloading Software Through The Network Interface Card (NIC)

---

1. Make a printout of all saved configurations. (Installing new software erases all saved configurations. You will use the printouts to restore the printer configurations.)
2. Set the printer power switch to O (Off).
3. On the printer panel, press and hold down the ONLINE + LF keys.  
  
Power the printer on, and continue holding the keys down until you see “TESTING HARDWARE PLEASE WAIT” on the LCD. You may then release the keys.
4. Wait until you see “WAITING FOR PROGRAM DOWNLOAD” on the LCD before proceeding. This can take up to 30 seconds to appear, depending on the emulations and interfaces installed in the printer.
5. Using Windows Explorer, create a directory named **download** at the root level of your C: hard drive.
6. Insert the printer emulation software CD into your computer.
7. Using Windows Explorer, navigate to the appropriate file on the CD (using the Unzipped directory) based on the printer type, and desired emulation.

## Chapter 9 Downloading Software Through The Network Interface Card (NIC)

---

8. Make note of the file name, which is a six digit number plus **.exe**, e.g., 123456.exe.  
**This is the file you will download into the NIC.**
9. Copy the file to the download directory.
10. Start a command prompt session. (The Start Menu icon is usually labeled MS-DOS Prompt or Command Prompt.)
11. At the command prompt type:  

```
c: <Enter>  
cd \download<Enter>
```
12. Ping the printer by typing:  

```
ping xx.xx.xx.xx<Enter>
```
13. Start the FTP download by typing:  

```
<file name> -n xxx.xxx.xxx.xxx<Enter>
```

(where xxx.xxx.xxx.xxx represents the IP Address of the printer and <file name> is the six digit number plus .exe.)

“Entering download mode” displays in the windows session. If the message does not appear, press Ctl-c to terminate the process and ping the printer’s IP address to ensure proper communication with the printer.

**CAUTION** Do not interrupt the downloading process once it has started. Interrupting a download will damage the flash memory on the controller board and NIC card.

14. When the new program has successfully loaded into flash memory and the printer has reset itself, set the printer power switch to O (off).
15. Unplug the AC power cord from the printer.
16. Remove the CD from the host computer and store it with the printer.
17. Using the configuration printout(s), reconfigure the printer and reload any optional font files.

## **NIC Naming Schemes**

---

A single I/O Port destination can be configured with a variety of model and logpath combinations. For instance, once you set the parameters for m1 and l1, you can assign the model and logpath to more than one I/O port destination such as d1prn, d2prn, and d8prn. You may now use the same set of model and logpath parameters more than once without having to redefine those parameters each time for another I/O Port destination.

## **Periodic Ping**

---

This feature when enabled executes background ping from the print server to its default gateway. The operation is executed on every user defined period. This mechanism has no TCP traffic from the print server to anything on the network to keep route information alive. Since every member in the VLAN is subject to aging from bridging cache, a switch or bridge in between may be forgotten in the table at which port the printer was connected. If one ping is run from printer server to its default gateway through the switch, the switch learns again and the route is seen. The problem will not be seen with TCP since the ACKs keep the bridge relearning in a switch. Periodically send ICMP Echo Request between a print server and its gateway that is typically situated in the same VLAN and connected with the same switch or bridge.

The printer server allows a periodic group of ping packets [1 – 5] to be issued by a set time [1– 5] minutes, to the gateway value the NIC has from its routing table. This feature can be enabled or disabled. The default is disable.

## Chapter 9 Periodic Ping

---

This periodic ping is different from the normal ping process. The purpose of this ping is not an attempt at dead gateway detection. There is no ping client created in the print server and the ICMP Echo Reply packets received from the gateway are deleted without being processed by the ping client. This reduces the processing load on the print server. The data size of ICMP Echo Request Message is set to 16 bytes such that the Ethernet frame is set to 64 bytes to minimize the impact of bandwidth on the network. This process applies to all the active NIC interfaces.

---



## *Troubleshooting Tips*

### **Windows Troubleshooting Tips**

---

This section provides information on possible solutions to some standard Windows and NIC configuration errors.

#### **Technical Support**

---

If you require technical support, please have the following information available when you call:

1. What level of software are you running?
2. What type of attachment do you have?
3. What is your host operating system?
4. Give a detailed description of the problem.
5. How often, and when, does the problem occur?
6. Give a detailed description of your network and the components attached.
7. Provide printer configuration and E-Net test page in either hardcopy or softcopy if possible.

## Appendix A Windows Troubleshooting Tips

---

### NIC Cannot Be Found On The Network

---

Please follow these tips to determine what the problem may be with your NIC configuration.

- Have you assigned the NIC a unique and valid IP address which corresponds with the other IP addresses on your network? For example, are you sure no other device is using this IP address? To find whether the IP address is unique, unplug your ethernet cable and ping the IP address to make sure it is not alive.
- Are you sure you are trying to talk to the NIC from a Windows station on the same subnet? The print server can only be seen locally unless you configured a routing entry earlier.
- Have you confirmed that the network connection to the NIC is working correctly? Trying different network cables and locations will help narrow down the problem.

### HTML Configuration Forms Will Not Display

---

- Can you ping NIC from the Windows station? If not, refer to “NIC Cannot Be Found On The Network” on page 140.
- Have you used the correct URL for the NIC home page? It should be `http://NICIPaddress` (e.g., `http://192.75.11.9`).
- Is HTTP support enabled? If not, refer to “Web Browser/HTTP Problem” on page 143.

---

## Errors Occur When Defining An LPR Printer

---

### Errors Occur When Defining An LPR Printer

---

- Can you ping the NIC from your Windows NT station? If not, please refer to “NIC Cannot Be Found On The Network” on page 140.
- Did you specify the correct IP address or host name for the NIC in the first field of the “Add LPR Compatible Printer” box?
- Did you specify a valid destination/queue on the NIC in the second field of the “Add LPR Compatible Printer” dialogue box? If so, did you also enter it in lowercase letters?

### Cannot Browse The NIC On The Network

---

- Have you looked under the right Windows workgroup? By default, the NIC will be found under “WORKGROUP.”
- Are you able to browse other Windows stations and devices on the network from this same station?
- Has this Windows station been given enough time to update its registry so it can see this newly added workgroup device? Sometimes Windows stations can take considerable time, depending on the size of the network.

## Appendix A Windows Troubleshooting Tips

---

### Printer Errors When Printing Or No Output

---

- Is there a large job currently printing which is taking up all of the printer resources? Usually when printing from Windows 95/98 stations, a busy printer can cause Windows to display a printer error message. This is because it demands immediate printer attention rather than holding the data until the printer is ready again. The best way around this is to use a central spooling station like an NT server.
- Have you tried restarting the spooler under “Control Panel:Services”? Sometimes this is needed to get printing started.

**NOTE:** As a last resort, you may want to reboot the Windows station. Sometimes this is the only option to completely clear this situation. The NIC usually has nothing to do with this problem.

### TCP/IP Access Problem

---

If you can ping the printer from a workstation, but you cannot Web browse, Telnet, or print to the printer through the NIC, there may be an incorrect entry in the TCP access list. In order for this workstation to use the NIC interface in this case, one of two things must happen.

- The TCP list must have an entry added to grant access to this workstation, or
- All entries must be deleted from the TCP list to grant all workstations/hosts access to the above TCP services.

To view the current access list, use the printer control panel to access the configuration menu (see the *User's Manual* for configuration menu information). From the DIAGNOSTICS/Printer Tests menu choose the E-Net Test Page. When the page prints, look under the “TCP ACCESS TABLE” section for the TCP access list entries.

---

## Web Browser/HTTP Problem

---

To add/delete a TCP access list entry, refer to “TCP Access Lists” on page 131.

**NOTE:** When the following procedure is used, the TCP access list will be cleared, but all IP addresses will need to be entered again after the procedure is complete.

To reset all Integrated NIC TCP/IP values to the factory defaults when access is impossible, contact your TallyGenicom service representative for assistance.

If you are still experiencing difficulty accessing or browsing the printer, contact the Customer Solutions Center for further assistance.

## Web Browser/HTTP Problem

---

In some cases, you may not be able to browse the printer Web page simply because the NIC HTTP may be turned off.

If you cannot ping the NIC IP address, make sure the IP Address, subnet mask, and default gateway are set correctly by checking the Ethernet Parameters menu from the operator panel. See the *User's Manual* for configuration menu information.

If you can ping the NIC IP address but cannot access the Web pages, perform the following procedure to verify the NIC HTTP is turned on.

1. **Telnet** into the NIC and log in as **root**. There is no password by default.
2. At the system prompt, enter the following commands:  

```
config http on
save
reset
```
3. After approximately 30 seconds, point your browser to the NIC IP address. The printer Web pages should now be accessible.

If you are still experiencing difficulty accessing or browsing the printer, contact the Customer Solutions Center for further assistance.

## Appendix A Windows Troubleshooting Tips

### Windows NT 4.0 Or 2000 Host Setup Problems

The installation procedure covered earlier in this chapter assumes that the NIC adapter is configured with the correct IP address, subnet mask and gateway (if required), and that the administrator can ping and telnet to the NIC adapter from the server console. If this is not the case, use the printer front panel to configure the NIC adapter before proceeding.

#### Installing Microsoft TCP/IP Printing

The NIC installation for Windows NT 4.0/2000 also requires the “Microsoft TCP/IP Printing” service on the server. To install this service, click the Network icon in the Control Panel and click the Services tab. Click **Add Service** and select Microsoft TCP/IP printing.


- Do you have administrative privileges?

This installation requires administrator privileges.

- “LPR port” is not listed.

Cancel the installation and install the Microsoft TCP/IP printing service on the server.

- LPR configuration warning.



## Windows NT 4.0 Or 2000 Host Setup Problems

---

The Ethernet cable is not plugged in or the printer is not turned on. This message is a communication failure between the NT/2000 server and the NIC. Check cabling, IP address settings, gateway, etc.

- Test page does not print or prints incorrectly:
  1. Is the printer online? Re-send test page.
  2. The print queue name should be d1prn; however, the name can be changed. To verify the queue names, print an E-Net Test Page. Refer to your *User's Manual* for information.
  3. The TallyGenicom NT print driver requires P-Series emulation active on the printer. The Generic/Text driver should print in any printer emulation.
  4. Delete then re-install the Microsoft TCP/IP Print service on the server.

If you are still experiencing difficulty accessing or browsing the printer, contact the Customer Solutions Center for further assistance.

## Appendix A Unix Troubleshooting Tips

---

### Unix Troubleshooting Tips

---

This section provides information on possible solutions to some standard configuration errors. If you require technical support, please have as much of the following information available when you call:

1. What level of software are you running?
2. What type of attachment do you have?
3. What is your host operating system?
4. How often, and when, does the problem occur?
5. Give a detailed description of the problem.
6. Give a detailed description of your network and the components attached.

#### NIC Cannot Be Found On The Network

---

- Have you configured the NIC with a unique and valid IP address which corresponds with the other IP addresses on your network? For example, are you sure no other device is using this IP address?
- Are you sure you are trying to talk to the NIC from a Unix station on the same subnet? Currently, the print server can only be seen locally unless you configured it with a routing entry.
- Have you confirmed that the network connection to the NIC is working correctly? Trying different network cables and locations will help narrow down the problem.

---

## Nothing Prints

---

- Can you `ping` the NIC from your Unix station? If not, please refer to “NIC Cannot Be Found On The Network” shown above.
- Is the NIC able to communicate with the attached printer? To test this, you can:
  1. `Telnet` to the print server (e.g., `telnet 192.75.11.9`) and log in as `root`.
  2. Enter the command `start fox prn`.
  3. Execute `stop prn` right after starting the test.
  4. This test will send the same text line over and over to the attached printer.
- Is the job getting stuck in the Unix host queue? If so, check that the printer is online. If it is, there is a configuration error on the Unix station, so creating a new print setup may be needed.
- Is the control panel showing any activity to indicate it is receiving data? If so, but there is nothing printing, check if a manual form feed is needed. Also, ensure that the printer can support the type of job coming through.
- Do all jobs fail or just certain ones? For example, is it possible that jobs from a certain application are the only ones to fail? If so, check the type of data it sends to make sure it matches the printer emulation. Check the application printer configuration for mistakes.
- If you are using System V, was the spooler restarted?

## Appendix A Unix Troubleshooting Tips

---

### Stair-Stepped Output

---

Stair-stepped output is print which starts at the top left of the page but every line thereafter starts a little further over to the right. It also refers to Unix jobs that print one line of text at the top of a page followed by a series of blank pages.

This kind of output happens only with Unix text jobs if carriage return insertion is not incorporated into the print setup. The printer may be told to do a linefeed, but the Unix job does not specify anything about a carriage return to follow this.

To fix this, carriage return insertion must be enabled somewhere in the print setup. The easiest and most common location is on the NIC itself within the appropriate model. The feature is called “onlcr” and the command syntax is:

```
set model modelname stty onlcr
save
```

For example, if printing to the destination, `d1prn`, the associated model is `m1`. Therefore, the command is:

```
set model m1 stty onlcr
save
```

---

## No Form Feed Or Extra Page Comes Out

---

### No Form Feed Or Extra Page Comes Out

---

Unix text jobs may also have problems outputting the last page of a job especially when the BSD Remote (LPD) print method is used. This means the form feed button has to be pressed on the printer to get this last page out.

To make this process automatic, tell the NIC to handle this task by setting this feature “on” in the appropriate model. The command syntax is:

```
set model modelName trailer $FF
save
```

For example, if printing to the destination, `d2prn`, the associated model is `m2`. Therefore, the command is:

```
set model m2 trailer $FF
save
```

For default destination model mappings of the NIC, please see “NIC Naming Schemes” on page 137.

### Front Panel Message – Dynamically Set Params Read Only

---

This is not an error. It is an informational message warning that the IP address has been dynamically set by either `dhcp`, `rarp`, or `bootp`.

To assign a static IP address, turn off the `rarp`, `bootp`, and `dhcp` on the adapter. Use the following procedure:

1. Telnet to the adapter. Login = root, password = (Enter key)

Telnet commands are:

```
store tcpip 1 opts -rarp -bootp -dhcp
save
reset
```

Wait two minutes for the adapter to reset.

2. Program the IP address, Subnet Mask and Gateway (if required) from the front panel.

**Appendix A** Unix Troubleshooting Tips

---

---

**B**

## *Customer Support*

### **TallyGenicom Customer Support Center**

---

**IMPORTANT** Please have the following information available prior to calling the TallyGenicom Customer Support Center:

- Model number
- Serial number (located on the back of the printer)
- Installed options (i.e., interface and host type if applicable to the problem)
- Help Menu printout (while offline press the MENU/ENTER key on the control panel to enter the menu. Press the Left Arrow key until the Help menu displays. Press the MENU/ENTER key).
- Is the problem with a new install or an existing printer?
- Description of the problem (be specific)
- Good and bad samples that clearly show the problem (faxing or emailing these samples may be required)

Americas (714) 368-2686

Europe, Middle East, and Africa (31) 24 6489 311

Asia Pacific (65) 6548 4114

China (86) 800-999-6836

<http://www.tallygenicom.com/service/default.aspx>

## Appendix B TallyGenicom Supplies Department

---

### TallyGenicom Supplies Department

---

Contact the TallyGenicom Supplies Department for genuine TallyGenicom supplies.

Americas	(800) 733-1900
Europe, Middle East, and Africa	33 (0) 1 46 25 19 07
Asia Pacific	(65) 6548 4116 or (65) 6548 4182
China	(86) 400-886-5598
India	(800) 102-7869

<http://www.tallygenicom.com/supplies/default.aspx>

### Corporate Offices

---

Printronix, Inc.  
15345 Barranca Parkway  
Irvine, CA 92618  
U.S.A.  
Phone: (714) 368-2300  
Fax: (714) 368-2600

Printronix Inc.  
c/o Printronix Nederland BV  
Bijsterhuizen 11-38  
6546 AS Nijmegen  
The Netherlands  
Phone: (31) 24 6489489  
Fax: (31) 24 6489499

Printronix Schweiz GmbH  
42 Changi South Street 1  
Changi South Industrial Estate  
Singapore 486763  
Phone: (65) 6542 0110  
Fax: (65) 6546 1588

---

Printronix Commercial (Shanghai) Co. Ltd  
22F, Eton Building East  
No.555, Pudong Av.  
Shanghai City, 200120, P R China  
Phone: (86) 400 886 5598  
Fax: (86-21) 5138 0564  
Visit the web site at [www.tallygenicom.com](http://www.tallygenicom.com)

**Appendix B Corporate Offices**

---

---

**C***Glossary*

<b>ARP</b>	Address Resolution Protocol. Associates a selected IP address with a network device Ethernet address.
<b>bps</b>	Bits per second.
<b>Centronics</b>	Parallel port interface standard found on most printers.
<b>daemon</b>	A continuously running process that handles system-wide functions like print spooling.
<b>default router</b>	Local device that forwards any IP packets destined for another subnet.
<b>destination</b>	Logical print queue on the NIC to which hosts send their print jobs. There are eight destinations by default.
<b>DHCP</b>	Dynamic Host Configuration Protocol. Allows a network device to discover its IP address dynamically upon bootup. The IP address does not need to be stored within the device itself permanently.
<b>Download Mode</b>	Refers to the condition of the NIC when in a startup condition, downloading configuration information.
<b>DNS</b>	Domain Name Server. Host providing responses to queries for a given host name IP address.

---

<b>EEPROM</b>	Electrically Erasable/Programmable Read-Only Memory.
<b>factory defaults</b>	Settings shipped with the NIC.
<b>Factory Settings</b>	S2 jumper position stating all factory default settings are to be used while the NIC is up and running.
<b>Flash</b>	Stores firmware code and configurable settings. Allows for upgrades without replacing hardware inside the NIC.
<b>FTP</b>	File Transfer Protocol. Used for transferring files from one TCP/IP host to another and used in the upgrade process.
<b>gateway</b>	Hardware device that translates data between two incompatible networks.
<b>gateway address</b>	The IP address of a gateway.
<b>Hardware Exception</b>	Bus errors, address errors, and illegal instructions force the NIC into this NIC non-operational mode.
<b>HTML</b>	HyperText Markup Language. Format used for documents viewable on the World Wide Web.
<b>ifnum</b>	Interface Number. Represents the network interface. With a NIC, this will always be "1" for Ethernet.
<b>interface script</b>	Unix host filter file that processes the print job before it is sent over the network to the NIC.
<b>I/O port</b>	Port for attaching peripherals to. The NIC provides four: PRN1, PRN2, COM1, COM2.
<b>IP Address</b>	The Internet Protocol Address. A numeric address such as 123.45.61.23 which identifies a printer or server in a LAN or WAN.

---

<b>LAN</b>	Local Area Network.
<b>logpath</b>	Determines the type of print job and printer logging needed per job. One logpath is associated with every destination.
<b>LPD/LPR</b>	Line Printer Daemon. The most common TCP/IP remote printing protocol that crosses all hardware utilizing IP.
<b>MAC</b>	Machine Address Code.
<b>MIB</b>	Management Information Base. A set of variables (database) managed by an SNMP manager application.
<b>model</b>	Defines how a print job should be processed (e.g., banner pages added, ASCII to PostScript conversion) as it passes through the NIC. One model is associated with every destination.
<b>NetBIOS</b>	Network Basic Input Output System. Common interface among PC networks.
<b>Monitor Mode</b>	Refers to the condition of the NIC with no configuration or IP address loaded.
<b>npsh</b>	Extensive built-in command shell within the NIC.
<b>PDF</b>	Portable Document Format. Encodes different types of documents enabling them to be read across multiple platforms.
<b>Persistent DHCP</b>	When this option is enabled, the IP Address, Gateway, and Subnet Mask obtained through DHSP is saved. If the DHCP server does not provide an address, the device will use the previously saved DHCP IP address. This option only works when DHCP is enabled. The default disable.

---


<b>ping</b>	Standard command to test a TCP/IP connection. (e.g., <code>ping 192.75.11.9</code> )
<b>print path</b>	Three-stage path a print job takes when it is sent from a host to a printer through the NIC.
<b>protocol</b>	A set of rules or conventions governing the exchange of information between computer systems or between a printer and a host computer. For computer printers, a protocol is the coding convention used to convey and print data. A printer protocol includes codes for printing text and graphics, as well as codes instructing the printer to perform special operations and machine-to-machine communication codes.
<b>PSERVER</b>	Print Server. A Novell print method where the NIC continuously polls the Novell file server print queue looking for print jobs.
<b>RAM</b>	Random Access Memory. Volatile memory within the NIC that contains current/working settings. Settings are lost once the power is removed.
<b>RARP</b>	Reverse Address Resolution Protocol. Allows a network device to discover its IP address dynamically upon bootup. The IP address does not need to be stored within the device itself permanently.
<b>ROM</b>	Read-Only Memory.
<b>router</b>	A device that forwards IP packets to their destination. Also called a gateway.
<b>RPRINTER</b>	Remote Printer. A Novell print method where the NIC waits for jobs to be sent to it from a defined PSERVER.

---

<b>SNMP</b>	Simple Network Management Protocol. A standard protocol used to monitor network devices called “SNMP agents.”
<b>socket</b>	TCP connection between two hosts consisting of a source and destination TCP port number at each end.
<b>subnet mask</b>	A binary value used to divide IP networks into smaller sub-networks or subnets. This mask is used to help determine whether IP packets need to be forwarded to other subnets.
<b>TCP/IP</b>	Transmission Control Protocol/Internet Protocol. Suite of protocols that act as the base protocol for the Internet.
<b>TCP port</b>	A logical connection point in the software of a TCP host or device. When two IP devices talk, they establish a socket which consists of a source and destination TCP port number on both ends.
<b>telnet</b>	Command and protocol to establish a terminal connection between two hosts on an IP network.
<b>UTP</b>	Unshielded Twisted Pair. A cable used for telephone and computer-to-computer connections.
<b>WAN</b>	Wide Area Network.



---



## Index

### Symbols

? command, 100

### Numerics

10/100Base-T, speed setting, 18

### A

Access lists, TCP, 131

Access methods, npsh, 99

ADDTCPIFC, configuring with, 83

ADDTCPRTE, router definition, 85

Administration, configuration, 49

Agent model, printer monitoring, 95

AIX NetView/6000, monitoring, 97

Alert groups, 48

ARP, Unix, 68

AS/400

    automatic remote output queue, 89

    configuring for ASCII, 83

    configuring for printing, 86

    CRTLINETH, 81

    hostname, 85

    local domain, 85

    remote printer queue name, 86

    TCP/IP host table entry, 85

    verify printing, 92

AS/400 ASCII, troubleshooting, 93

ASCII

    configuring AS/400, 83

    setting up for printing, 86

Automatic remote output queue,

AS/400, 89

### B

Back Channel, Print Path, 36

Banner Page, 41

Banner Page, Print Path, 38

BOOTP, Unix, 71

Browse NIC, troubleshooting, 141

### C

Change destination names, NIC, 60

Command prefixes, 100

    npsh, 100

Command Shell, 99

    ways to access, 26

Commands

    ?, 100

    complete list, 101

    getting help, 100

    list, 122

    miscellaneous, 124

    set, 109

    store, 101

Communication routers, Windows, 58

## Index

---

### Configuration

- administration, 49
- control panel, 23
- IP Address, 25
- Log Path, 43
- network, 32
- Print Model, 40
- Print Path, 35
- SNMP, 45
- System, 53

- Configuration menu, NIC, 30
- Configuration tools, 21
- Connecting to the network, 21
- Control panel message, Dynamically Set Params Read Only, 149
- Control panel, configuration, 23
- CRTLINETH, line descriptions, 81
- Customer Support Center, 151

### D

- Define LPR printer, error, 141
- Destination settings, Print Path, 35
- Destinations
  - models, 17
  - NIC, 17
- Direct socket printing, 79
- Document conventions, 20
- Dynamically Set Params Read Only message, 149

### E

- E-mail alert posting, 46
- Errors, defining LPR printer, 141

### F

- Filter, Print Model, 41
- Filter, Print Path, 38
- FTP printing, 78

### G

- Getting Help command, 100
- Guest user, NIC, 129

### H

- Header String, Print Model, 41
- Header String, Print Path, 39
- Help, 54
- Help command, getting, 100
- Home page, URL, 26
- Host configuration, Unix, 73
- Host setup, Printer Driver Setup Wizard, 62
- HP-UX, 74
- HTML forms, 26
- HTTP, troubleshooting, 143

### I

- I/O Port, status, 54
- Installation
  - HP-UX, 74
  - Solaris 2.6, 75
- Installation Solaris 7, 75
- Installation, NIC, 21
- IP Address Configuration, 25

**L**

Line descriptions, CRTLINETH, 81  
List commands, 122  
Log Path  
    configuration, 43  
    Logpath Port, 44  
    Logpath Type, 43  
    Name, 43  
Log Path Port, Print Path, 39  
Log Path Type, Print Path, 39  
Logging, printer, 133  
Logical printer architecture, 15  
Logpath Port, Log Path, 44  
Logpath Type, Log Path, 43  
Logpaths, printer logging, 134  
LPR/LPD Host setup, 76

**M**

Manager model, printer monitoring, 95  
Manual  
    notes, 20  
    notices, 20  
Manual LPR/LPD Host setup, 76  
Manual system, V Host setup, 73  
MIB, 96  
Microsoft TCP/IP printing, 144  
Miscellaneous commands, 124  
Model Type, Print Model, 40  
Model Type, Print Path, 37  
Models, 17  
    setting a formfeed, 149  
    setting onlcr, 148

**Monitoring**

print job, 133  
printer, 133

**N****Name**

Log Path, 43  
Print Model, 40  
Print Path, 36

Naming schemes, NIC, 137

**Network**

configuration, 32  
connection, 21  
NIC cannot be found, 140  
status, 54  
TCP/IP, 32

Network Addressing, TCP/IP Network, 33

Network Interface Card, 13

**NIC, 13**

cannot be found, 140  
cannot be found on network,  
    troubleshooting, 146  
change destination names, 60  
configuration menu, 30  
configuration, Windows, 56  
destinations, 17  
guest user, 129  
installation, 21  
naming schemes, 137  
passwords, 129  
queues, 17  
reset password, 131  
root user, 129

## Index

---

- security, 129
  - special features, 13
  - users, 129
  - verification, 24
  - No extra page, troubleshooting, 149
  - No form feed, troubleshooting, 149
  - Notes, 20
  - Notices, 20
  - Npsh
    - access methods, 99
    - command prefixes, 100
- O**
- Onlcr, 148
- P**
- Passwords, 52
    - NIC, 129
    - reset, 131
  - Periodic Ping, 137
  - PNE, 98
  - Prefixes, command, 100
  - Print job monitoring, 133
  - Print Model, 41
    - Banner Page, 41
    - configuration, 40
    - Filter, 41
    - Header String, 41
    - Model Type, 40
    - Name, 40
    - Printer Configuration, 42
    - Trailer String, 41
  - Print Path
    - Back Channel, 36
    - Banner Page, 38
    - configuration, 35
    - destination settings, 35
    - Filter, 38
    - Header String, 39
    - Log Path Port, 39
    - Log Path Type, 39
    - Model Type, 37
    - Name, 36
    - Printer Configuration, 39
    - Selected Log Path, 39
    - Selected Model, 36
    - Services, 36
    - Trailer String, 39
  - Printer
    - errors, 142
    - logging, 133
    - logging through logpaths, 134
    - monitoring, 133
  - Printer Configuration
    - Print Model, 42
    - Print Path, 39
  - Printer Driver Setup Wizard, 62
  - Printer management implementation, 95
  - Printer monitoring
    - Agent model, 95
    - Manager model, 95
    - MIB, 96
    - SNMP, 97
    - tools, 97

**Printing**

- ASCII, 86
- configuration, AS/400, 86
- direct socket, 79
- FTP, 78
- troubleshooting, 147
- verification, AS/400, 92

PrintNet Enterprise Suite, 98

**Q****Queues**

- models, 17
- NIC, 17

**R**

RARP, Unix, 70

Remote shell, 27

Root user, NIC, 129

Routers, Unix, 72

Routing, TCP/IP Network, 34

**S**

Security, NIC, 129

Selected Log Path, Print Path, 39

Selected Model, Print Path, 36

Services, Print Path, 36

Set commands, 109

Setup through Data Stream, 28

Shell, command, 99

SNMP, 97

- community name, 98
- configuration, 45
- manager alert posting, 45

Solaris 2.6, 75

Solaris 7, 75

Special features, NIC, 13

Speed setting, 10/100Base-T, 18

Stair-stepped output, troubleshooting, 148

**Status**

I/O Port, 54

menu, 53

Network, 54

Store commands, 101

Supplies Department, 152

Syslog alert posting, 46

**System**

configuration, 53

information, 50

**T**

TCP access lists, 131

**TCP/IP**

access, troubleshooting, 142

configuring AS/400 for ASCII, 83

TCP/IP Network, 32

Network Addressing, 33

Routing, 34

Technical support, 139

Telnet, 27

Tools, printer monitoring, 97

**Trailer String**

Print Model, 41

Print Path, 39

## Index

---

### Troubleshooting

- AS/400 ASCII, 93
- cannot browse NIC on Network, 141
- defining LPR printer, 141
- HTML configuration forms, 140
- HTTP, 143
- NIC cannot be found, 140
- NIC cannot be found on Network, 146
- no extra page, 149
- no form feed, 149
- printer errors, 142
- printing, 147
- stair-stepped output, 148
- TCP/IP access problem, 142
- Unix, 146
- Web browser, 143
- Windows, 139
- Windows 2000 Host setup, 144
- Windows NT 4.0 Host setup, 144

### U

### Unix

- crossing routers, 72
- environment, 67
- Host configuration, 73
- manual system V Host setup, 73
- NIC configuration, 68
- troubleshooting, 146
- using ARP, 68
- using BOOTP, 71
- using RARP, 70

- Unix troubleshooting, Dynamically Set  
Params Read Only message, 149

- URL, home page, 26
- Usage information, Windows driver, 65
- Users, NIC, 129
- Using ARP, Windows, 56

### V

- V Host setup, manual system, 73
- Verification, NIC, 24

### W

- Web browser, troubleshooting, 143
- Web server, overview, 29

### Windows

- communication routers, 58
- configuration, 55
- environment, description, 55
- mandatory configuration, 56
- NIC configuration, 56
- optional configuration, 56
- troubleshooting, 139
- using ARP, 56
- Windows 2000, Host setup  
troubleshooting, 144
- Windows Driver, usage information, 65
- Windows NT 4.0, Host setup  
troubleshooting, 144





255553-001C